

Version: EN-UM-1.2

USER MANUAL

Three-phase Hybrid Inverter

HISTORY

| VERSION | ISSUED | COMMENTS |
|---------|------------|---|
| 1.0 | 11-Jan.-23 | First release |
| 1.1 | 27-Apr.-23 | Revise M12 expansion screws to M10. Update the packing List, left side Appearance, LED description and the related details of the external button and the removal tool of Grid/BACKUP connector. |
| 1.2 | 15-Jun.-23 | Add PV connection warning. |

Preface

About This Manual

This manual describes the installation, electrical connection, commissioning and maintenance, APP operation of the inverter. Please first read the manual and related documents carefully before using the product and store it in a place where installation, operation and maintenance personnel can access it at any time. The illustration in this user manual is for reference only. This user manual is subject to change without prior notice. (Specific please in kind prevail.)

Target Group

Three phase hybrid inverters must be installed by professional electrical engineers who have obtained relevant qualifications.






Scope

This manual is applicable to the following inverters:

- 5K
- 6K
- 8K
- 10K

Conventions

The following safety instructions and general information are used within this user manual.

| | |
|--|---|
|  DANGER | Indicates an imminently hazardous situation which, if not correctly followed, will result in serious injury or death. |
|  WARNING | Indicates a potentially hazardous situation which, if not correctly followed, will result in serious injury or death. |
|  CAUTION | Indicates a potentially hazardous situation which, if not correctly followed, could result in moderate or minor injury. |
|  NOTICE | Indicates a potentially hazardous situation which, if not correctly followed, could result in equipment failure to run, or property damage. |
|  NOTE | Call attention to important information, best practices and tips: supplement additional safety instructions for your better use of the Three phase hybrid inverter to reduce the waste of you resource. |

CONTENTS

Preface

About This Manual

Target Group

Scope

Conventions

1. Safety

1.1 Symbols Used

1.2 Safety Precaution

2. Product Introduction

2.1 Overview

2.2 Product Appearance

2.3 Model Definition

3. Installation

3.1 Packing List

3.2 Selecting the Mounting Location

3.3 Mounting

4. Electrical Connection

4.1 Grounding

4.2 GRID/BACKUP Connection

4.3 Battery Connection

4.4 PV Connection

4.5 Meter/CT Connection

4.6 Communication Connection

5. System Operation

5.1 Inverter Working Mode

5.2 Startup/Shutdown Procedure

6. Commissioning

6.1 Inspection

6.2 Commissioning Procedure

7. User Interface

7.1 LED

7.2 App Setting Guide

8. Maintenance

8.1 Routine Maintenance

8.2 Inverter Troubleshooting

8.3 Removing the Inverter









9. Technical Specifications

1. Safety

Before using the inverter, please read all instructions and cautionary markings on the unit and manual. Put the instructions where you can take them easily.

The three phase hybrid inverter of ours strictly conforms to related safety rules in design and test. Local safety regulations shall be followed during installation, operation and maintenance. Incorrect operation work may cause injury or death to the operator or a third party and damage to the inverter and other properties belonging to the operator or a third party.

1.1 Symbols Used

| Safety Symbol | Description |
|---|--|
|  | Danger of high voltage! Only qualified personnel may perform work on the inverter. |
|  | Residual voltage exists after the inverter is powered off. It takes 5 minutes for system to discharge to a safe voltage. |
|  | Danger of hot surface |
|  Do not disconnect under load! | Do not disconnect under load, otherwise there will be a danger of fire. |
|  | Environmental Protection Use Period |
|  | Refer to the operating instructions |
|  | Don't dispose of the inverter with the household waste. |
|  | Grounding terminal |

1.2 Safety Precaution

- Installation, maintenance and connection of inverters must be performed by qualified personnel, in compliance with local electrical standards, wiring rules and requirements of local power authorities and/or companies.
- After the inverter is powered off, the remaining electricity and heat may still cause electric shock and body burns. Do not touch parts of inverter for 10 minutes after disconnection from the power sources.
- The temperature of some parts of the inverter may exceed 60°C during operation. Do not touch the inverter during operation to avoid being burnt.
- Ensure children are kept away from inverters.
- Don't open the front cover of the inverter. A part from performing work at the wiring terminal (as instructed in this manual), touching or changing components without authorization may cause injury to people, damage to inverters and annulment of the warranty.
- Static electricity may damage electronic components. Appropriate method must be adopted to prevent such damage to the inverter; otherwise the inverter may be damaged and the warranty annulled.
- Ensure the output voltage of the proposed PV array is lower than the maximum rated input voltage of the inverter; otherwise the inverter may be damaged and the warranty annulled.
- When exposed to sunlight, the PV array generates dangerous high DC voltage. Please operate according to our instructions, or it will result in danger to life.
- PV modules should have an IEC61730 class A rating.
- If the equipment is used in a manner not specified by the manufacturer, the protection provided by the equipment may be impaired.
- Completely isolate the inverter before maintaining. Completely isolate the inverter should: turn off the PV switch and disconnect the PV terminal, battery terminal, and AC terminal
- Prohibit inserting or pulling the AC and DC terminals when the inverter is running.
- In Australia, the inverter internal switching does not maintain the neutral integrity, neutral integrity must be addressed by external connection arrangements.
- Don't connect Three phase hybrid inverter in the following ways:
The BACKUP Port should not be connected to grid;
The single PV panel string should not be connected to two or more inverters.


2. Product Introduction

2.1 Overview


Hybrid Inverter


The hybrid inverters are high-quality inverter which can convert solar energy to AC energy and store energy into battery.

The inverter can be used to optimize self consumption, store in the battery for future use or feed into public grid. Work mode depends on PV energy and user's preference. It can provide power for emergency use during the grid lost by using the energy from battery and inverter (generated from PV).



2.2 Product Appearance






2.3 Model Definition

The letters in the product model have the specific informations.


(Take 5K as example.)



3. Installation

3.1 Packing List

After unpacking, please check the following packing list carefully for any damage or missing parts. If any damage or missing parts occurs, contact the supplier for help.




| Number | Quantity | Description |
|--------|------------------------------|--|
| A | 1 | Inverter |
| B | 1 | Mounting bracket |
| C | 1 | File package |
| D | 2/2 for 5/6K; 3/3(for 8/10K) | PV terminal connector group (PV+/PV-) ; |
| E | 2 | Grid/BACKUP connector |
| F | 1/1 | Battery terminal connector group (BAT+/BAT-) ; |
| G | 1 | Meter (Optional) |
| H | 1 | CT pack (3pcs CT + 1pcs 6-Pin terminal) |
| I | 3 | M10 Expansion screws |
| J | 1 | M6 Security screw |
| K | 1 | WiFi/LAN module (Optional) |
| L | 1 | 9-Pin terminal |
| M | 2 | 4-Pin terminal |
| N | 1 | Removal tool for PV/BAT connector |
| O | 1 | Removal tool for Grid/BACKUP connector |
| P | 1 | Battery Temperature sensor (Optional) |

3.2 Selecting the Mounting Location


3.2.1 Installation Environment Requirements

- The storage inverter protection class is IP65 and can be mounted indoors or outdoors.
- To ensure optimum operation and long service life, the ambient temperature must be below 50°C.
- Do not install the inverter in a rest area since it will cause noise during operation.
- The inverter carrier must be fire-proof. Do not mount the inverter on flammable building materials.
- Ensure that the wall meets the requirements of the inverter installation.
- Product label and warning symbols shall be clear to read after installation.
- The installation height should be reasonable and make sure it is easy to operate and view the display.
- Please avoid direct sunlight, rain exposure, snow cover.





3.2.2 Mounting Requirements

Mount the inverter vertically or tilted backward by max 15°. The device can not be installed with a wrong mode and the connection area must point downward.



3.2.3 Installation Space Requirements

To ensure the inverter normally and easy to operate, there are requirements on available spaces of the inverter, e.g. to keep enough clearance. Refer to the following figures.




3.3 Mounting


Before mounting the inverter, you have to prepare expansion screws and security screw.



Step 1. Install the mounting bracket

1. Use a level ruler to mark the position of the 3 holes on the wall. Refer to Figure a. And drill 3 holes, 16mm in diameter and 55mm in deep. Refer to Figure b.
2. Knock the expansion screw kit into the hole together with a hammer. Refer to Figure c.
Note: Do not remove the nut unit in this step.
3. After tightening 2-3 buckles, the expansion bolts are tight and not loose, and then unscrew the bolts, spring washer, gasket. Refer to Figure c.
4. Install and fix the mounting bracket on the wall. Refer to Figure d.



Step 2. Install the inverter on the mounting bracket. Then lock the inverter using the security screw. Refer to Figure e, Figure f.




| | |
|--|---|
|  DANGER | <p>Before frilling the hole on the wall, ensure no damage on the electric wire and/or water pipe inside the wall.</p> |
|  CAUTION | <p>To prevent potential damages and injuries from inverter falling down, please hang the inverter on the bracket, do not loosen grip unless confirm the inverter is well mounted.</p> |

4. Electrical Connection


This chapter shows the details connection of Three phase hybrid inverter. The following illustration only uses the hybrid inverters as an example.

Three phase hybrid inverter system connection diagram:

Connection mode for whole-house load



Non-parallel connection mode









Note

1. BMS communication connection is only for lithium battery.
2. Meter is optional.
3. About breakers: DC breaker on BATTERY side $\geq 80\text{A}$; AC breaker on critical load side $\geq 40\text{A}$; AC breaker on Inverter side $\geq 40\text{A}$


| | |
|---|---|
| <b style="font-size: 1.2em;">DANGER | Ensure that inverter and all cables to be installed are completely powered off during whole installation and connection. Otherwise, fatal injury can occur due to the high voltage. |
|---|---|

Three phase parallel connection mode-Scheme A (N=2)

- COM ———
- L1 ———
- L2 ———
- L3 ———
- N ———
- PE ———
- Breaker 



- ① Parallel communication connection
 - ② CT/Meter communication connection
 - ③ BMS communication connection
- * These communication cables can be connected to any inverter, but they must be inserted into the same inverter and we call this inverter No. 1 inverter.



Note for Scheme A:


1. BMS communication connection is only for lithium battery.
2. With parallel connection mode, it is necessary to connect APP to one of inverters and then go to [Console > Other Setting](#) page to enable [Parallel mode](#) on APP. Please refer to section 7.2.3.
3. About breakers:
DC breaker on BATTERY side $\geq 80A$
AC breaker on critical load side $\geq 40A$
AC breaker on Inverter side $\geq 40A$





DANGER

Ensure that inverter and all cables to be installed are completely powered off during whole installation and connection. Otherwise, fatal injury can occur due to the high voltage.

Three phase parallel connection mode-Scheme B (N>2)

- COM ———
- L1 ———
- L2 ———
- L3 ———
- N ———
- PE ———
- Breaker 




- ① Parallel communication connection
- ② Meter communication connection
- ③ BMS communication connection

* These communication cables can be connected to any inverter, but they must be inserted into the same inverter and we call this inverter No. 1 inverter.




Note for Scheme B:


1. BMS communication connection is only for lithium battery.
2. It is necessary to turn the matched resistance switch of No. 1 inverter and No. N inverter to “ON” in parallel connection mode.
3. With parallel connection mode, it is necessary to connect APP to one of inverters and then go to [Console > Other Setting](#) page to enable **Parallel mode** on APP. Please refer to section 7.2.3.
4. About breakers:
DC breaker on BATTERY side $\geq 80A$
AC breaker on critical load side $\geq 40A$
AC breaker on Inverter side $\geq 40A$


| | |
|---|--|
|  DANGER | Ensure that the inverter and all cables to be installed have been completely powered off during the whole process of installation and connection. Otherwise, fatal injury could be caused by the high voltage. |
|---|--|

4.1 Grounding

A protective earth (PE) terminal is equipped at the side of the inverter. Please be sure to connect this PE terminal to the PE bar for reliable grounding. AWG 10 yellow green lines are recommended.





| | |
|--|---|
|  WARNING | The inverter must be grounded; otherwise, there may be electric shock risk. |
|--|---|

| | |
|--|--|
|  CAUTION | If the positive pole or negative pole of the PV array is required to be grounded, then the inverter output (to AC grid) must be isolated by transformer in accordance with IEC62109-1, -2 standards. |
|--|--|

4.2 GRID/BACKUP Connection

If necessary, please refer to below to disassemble the GRID/BACKUP terminal.



Before connecting the GRID/BACKUP terminal, ensure that both the AC terminal and the DC terminal are powered OFF and the PV switch is OFF. Otherwise there is a risk of high voltage shock.


GRID/BACKUP connection please refer to below.

Step 1: Assemble the AC connector.

It is recommended to use outdoor dedicated cables with multiple copper cores.

| | |
|---------------------------|---------------------|
| D (Diameter): | 18 ~ 24mm |
| S (Cross sectional area): | $\geq 5\text{mm}^2$ |
| L (Length): | $16 \pm 1\text{mm}$ |
| L1: | $60 \pm 2\text{mm}$ |

1 Wire stripping.



Step 2: Connect the AC connector.

An AC breaker should be installed between inverter and the GRID/BACKUP.

- a. Before connecting the AC cable from inverter to AC breaker, you should confirm the AC breaker is working normally. Turn off the AC breaker and keep the status.
- b. Connect the PE conductor to grounding electrode, and connect the N and L conductors to AC breaker.
- c. Connect the AC breakers to the GRID/BACKUP.



NOTICE

- Multiple inverters are not allowed to share a circuit breaker.
- Load is not allowed to connect between the grid and the AC breaker.

To ensure that the inverter can be safely and reliably disconnected from the grid, an AC breaker ($\geq 40A$) should be installed only for inverter GRID/BACKUP port.


4.3 Battery Connection

Three phase hybrid inverter now only supports the lithium / lead-acid battery. The recommended lithium battery brands are as follows: PYLON LPF, Aoboet LPF, Dyness LPF, UZENERGY L051100-A.

This part in this manual only describe the battery connection on inverter side. If you need more detailed connection information about the battery side, please refer to the manual of the battery you using.

Before connecting to battery, please install a separate DC breaker between inverter and battery.

This ensure the inverter can be security disconnected during maintenance.




Diameter 7.5-8.5mm

8mm


8mm

Using crimping tool to stitching. Limit buckle can't be crimped.




Click

Positive Connector




Negative Connector



a Cross sectional area of the battery cable: 10mm² (recommended)
Length of the battery cable should be less than or equal to 3m.

Pay attention to the difference between the battery terminal and the PV terminal to avoid confusion.

DC Breaker 80A




It is recommended that the battery cable be less than or equal to 3 m.

This product is not equipped with DC breakers.


b


Positive Connector



Click

Negative Connector






BAT+

BAT-

Warning!
Polarity reverse will damage the inverter!

c


| | |
|---|---|
|  <p>WARNING</p> | <ul style="list-style-type: none"> Polarity reverse will damage the inverter! Be careful of electric shock and chemical hazards! To reduce risk of injury, please use the suitable recommended cable size. |
|---|---|

Battery Communication Connection

If the battery type is lithium battery which need communication between the inverter and battery management system (BMS), the connection must be installed. Please refer to section 4.6.1 for details.

Three-phase Hybrid Inverter User Manual 23

NTC connection for lead-acid battery





4.4 PV Connection

PV connection please refer to below.

The diagram illustrates the PV connection process in several stages:

- Preparation:** Two cables with a diameter of 4-6mm are shown. The positive cable is red and the negative is black. Both have 4mm crimped ends. A "Limit buckle" is indicated on the positive cable, with a note: "Using crimping tool to stitching. Limit buckle can't be crimped."
- Connection:** The cables are inserted into a terminal block. The positive connector is red and the negative is black. A "Click" sound is indicated when the cables are fully seated.
- Testing:** A digital multimeter is used to test the string voltage, showing a reading of 800.0. A note says: "Test string voltage and confirm string polarity."
- Switch:** A circular diagram shows a switch being turned from "ON" to "OFF". A note says: "Ensure that the PV switch is OFF."
- Final Note:** "Tighten the waterproof nuts on each connector with a tool to avoid loosening."
- General Note:** "Note: DC cable should be dedicated PV cable (suggest using 4~6mm² PV1-F cable)."

| | |
|---|--|
|  <p>NOTICE</p> | <ul style="list-style-type: none"> • Before connection the PV panels, make sure the plug connector have the correct polarity. Incorrect polarity could permanently damage the inverter. • PV array shouldn't be connected to the grounding conductor. • The minimum insulation resistance to ground of the PV panels must exceed 33.3kΩ, there is a risk of shock hazard if the requirement of minimum resistance is not met. |
|---|--|

| | |
|---|--|
|  <p>WARNING</p> | <p>Please check polarity of PV connectors! If polarity reversed, do not try to disconnect any PV connector until the irradiance declines and the DC currents fall below 0.5 A! Only then disconnect the PV plugs and correct the polarity before reconnecting.</p> |
|---|--|

4.5 Meter/CT Connection (Direct connect)


You can monitor usage with a meter or a CT.

4.5.1 Meter Connection

This section is applicable to non-parallel connection mode only.


Three phase hybrid inverter supports the meter CHINT-DTSU666 meter by default.

The meter is optional.



Before connecting to Grid, please install a separate AC breaker ($\geq 40A$; not equipped) between meter and Grid. This ensure the inverter can be security disconnected during maintenance.

The connection diagram of power cable of meter is as shown in the figure below:




Please refer to the meter instruction manual for details.


4.5.2 CT Connection

Before connecting to Grid, please install a separate AC breaker ($\geq 40A$; not equipped) between CT and Grid. This ensure the inverter can be security disconnected during maintenance.

The connection diagram of power cable of CT is as shown in the figure below:




Please attention to the Current interchanger (CT) connection. The arrow on the CT indicates the current flow from grid to inverter. And lead the live line through the detection hole of CT.

| | |
|---|--|
|  NOTE | The current direction from grid to inverter is defined as positive and current direction from inverter to grid is defined as negative. |
|---|--|

4.6 Communication Connection


There are communication interfaces in the communication port on the bottom of the inverter as show below:



| Interface | | Descriptions |
|-----------|-----|--|
| PARA | | 4-Pin interface for parallel communication |
| | | A matched resistance switch for parallel communication |
| RS485 | | RS485 communication |
| DRMs | | Demand response mode for Australia application |
| CT | | 6-Pin interface for grid/load current sensor. |
| BMS | | Lithium battery communication interface |
| 9-Pin | NTC | Temperature sensor terminal of lead-acid battery |
| | DRY | DI/DO control |
| RSD/RMO | | RSD control power and remote off |
| COM | | For WIFI/LAN communication. |

4.6.1 BMS Connection (Only for Lithium Battery)

RJ45 Terminal Configuration of Battery Communication (BMS)



| | | | | |
|-----------------------------|---------|---------|-----|-------|
| PIN | 1 | 2 | 3 | 4 |
| Function Description | RS485_A | RS485_B | GND | CAN_H |
| PIN | 5 | 6 | 7 | 8 |
| Function Description | CAN_L | / | / | / |

This manual describes the cable sequence of the inverter. For details about the cable sequence of the battery, see the manual of the battery you used.

Refer to the following steps:

a Unscrew the waterproof cover and loosen the rubber nut on waterproof cover.

c

- ① Insert RJ45 terminals into corresponding ports.
- ② Screw the waterproof cover back to inverter firmly with 4 x M4 screws(1.2N·m).
- ③ Install the seal into the threaded sleeve, fasten the rubber nut.

b Make the RJ45 terminal according to above function description of each Pin definition. Lead the BMS cable through the rubber nut, seal and waterproof cover in turn.

Don't cut off any communication cables.


Press the BMS cable in the seal via the side incisions.

4.6.2 DRMs Connection

DRMs is a shortened form for “inverter demand response modes”. It is a compulsory requirements for inverters in Australia.

Note: With DRMs connection, it is necessary to connect APP to inverter and then go to [Console > Other Setting](#) page to enable [DRM function](#) on APP. Please refer to section 7.2.3.

RJ45 Terminal Configuration of DRMs



DRMs

| PIN | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 |
|----------------------|---------|---------|---------|---------|-----|-----|---|---|
| Function Description | DRMs1/5 | DRMs2/6 | DRMs3/7 | DRMs4/8 | REF | GND | / | / |

Refer to the following steps:

a Unscrew the waterproof cover and loosen the rubber nut on waterproof cover.

c

- ① Insert RJ45 terminals into corresponding ports.
- ② Screw the waterproof cover back to inverter firmly with 4 x M4 screws(1.2N·m).
- ③ Install the seal into the threaded sleeve, fasten the rubber nut.

b Make the RJ45 terminal according to above function description of each Pin definition. Lead the DRMs/RCR cable through the rubber nut, seal and waterproof cover in turn.

DRMs Control Module

DRMs/RCR cable

Rubber nut

Seal

Threaded sleeve

Waterproof cover

RJ45 terminals


Inverter side

! Don't cut off any communication cables.

Press the DRMs cable in the seal via the side incisions.

4.6.3 Monitoring/Meter Connection


RJ45 Terminal Configuration of Monitoring/Meter Communication






| PIN | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 |
|----------------------|---------|---------|---|---|---|---|---------|---------|
| Function Description | RS485_A | RS485_B | / | / | / | / | RS485_A | RS485_B |

Meter cable connection overview

| Inverter | Meter |
|---------------|-------|
| Pin7(RS485_A) | Pin24 |
| Pin8(RS485_B) | Pin25 |




Connect meter. Refer to the following steps:

| | |
|---|--|
|  <p>a Unscrew the waterproof cover and loosen the rubber nut on waterproof cover.</p> |  <p>c</p> <ol style="list-style-type: none">① Insert RJ45 terminals into corresponding ports.② Screw the waterproof cover back to inverter firmly with 4 x M4 screws(1.2N·m).③ Install the seal into the threaded sleeve, fasten the rubber nut. |
| <p>b Make the RJ45 terminal according to above function description of each Pin definition. Lead the meter communication cable through the rubber nut, seal and waterproof cover in turn.</p>  <p>! Don't cut off any communication cables.</p> <p>Press the meter cable in the seal via the side incisions.</p> | |

4.6.4 CT Connection

CT cable connection overview



Connect CT. Refer to the following steps:

a Unscrew the waterproof cover and loosen the rubber nut on waterproof cover.

c

- ① Insert RJ45 terminals into corresponding ports.
- ② Screw the waterproof cover back to inverter firmly with 4 x M4 screws (1.2N·m).
- ③ Install the seal into the threaded sleeve, fasten the rubber nut.

b Make the 6-pin terminal according to above function description of each Pin definition. Lead the CT cable through the rubber nut, seal and waterproof cover in turn.

Don't cut off any communication cables.

Press the CT cable in the seal via the side incisions.


4.6.5 Parallel Communication Connection

4-Pins Terminal Configuration of parallel Communication



| PIN | 1 | 2 | 3 | 4 |
|----------------------|-------|-----------|-------|-------|
| Function Description | GND_S | PARA_SYNC | CAN_L | CAN_H |


Parallel communication cable connection overview



It is necessary to turn the matched resistance switch of No. 1 inverter and No. N inverter to "ON" in parallel connection mode.


| No. 1 Inverter | No. 2 Inverter | | No. N Inverter |
|-----------------|-----------------|-------|-----------------|
| Pin4(CAN_H) | Pin4(CAN_H) | | Pin4(CAN_H) |
| Pin3(CAN_L) | Pin3(CAN_L) | | Pin3(CAN_L) |
| Pin2(PARA_SYNC) | Pin2(PARA_SYNC) | | Pin2(PARA_SYNC) |
| Pin1(GND_S) | Pin1(GND_S) | | Pin1(GND_S) |

Refer to the following steps:



Unscrew the waterproof cover and loosen the rubber nut on waterproof cover.

a





- ① Insert 4-Pin terminal into corresponding ports.
- ② Screw the waterproof cover back to inverter firmly with 4 x M4 screws(1.2N·m).
- ③ Install the seal into the threaded sleeve, fasten the rubber nut.

c


b

Make the 4-Pin terminal according to above function description of each Pin definition.
Lead the Parallel cable through the rubber nut, seal and waterproof cover in turn.





Don't cut off any communication cables.




Press the Parallel communication cable in the seal via the side incisions.

4.6.6 NTC/DI/DO Connection(s)

9-Pins Terminal Configuration of Auxiliary Communication

Pin 123456789



| PIN | Function Description |
|-----|----------------------|
| 1 | NO (Normal Open) |
| 2 | COM |
| 3 | NC (Normal Close) |
| 4 | NO (Normal Open) |
| 5 | COM |
| 6 | NC (Normal Close) |
| 7 | DI |
| 8 | GND S |
| 9 | NTC BAT+ |

Refer to the following steps:

a

Unscrew the waterproof cover and loosen the rubber nut on waterproof cover.


b

Make the 9-Pin terminal according to above function description of each Pin definition for the auxiliary port you want to use.

Lead the NTC/DI/DO cable(s) through the rubber nut, seal and waterproof cover in turn.


Don't cut off any communication cables.

Press the NTC/DI/DO cable(s) in the seal via the side incisions.








4.6.7 RSD/RMO Connection(s)

4-Pins Terminal Configuration of RSD/RMO Communication



| PIN | 1 | 2 | 3 | 4 |
|----------------------|------|-----|-----|------------|
| Function Description | +12V | GND | GND | REMOTE OFF |


Refer to the following steps:

| | |
|--|---|
|  <p>Unscrew the waterproof cover and loosen the rubber nut on waterproof cover.</p> <p>a</p> |  <ol style="list-style-type: none">① Insert 4-Pins terminal into corresponding ports.② Screw the waterproof cover back to inverter firmly with 4 x M4 screws(1.2N·m).③ Install the seal into the threaded sleeve, fasten the rubber nut. <p>c</p> |
| <p>b</p> <p>Make the 4-Pin terminal according to above function description of each Pin definition. Lead the RSD/RMO cable through the rubber nut, seal and waterproof cover in turn.</p>  <p>Another inverter side</p> <p>RSD/RMO communication cable</p> <p>Threaded sleeve</p> <p>4-Pin terminal</p> <p>Inverter side</p> <p>Rubber nut</p> <p>Seal</p> <p>Waterproof cover</p> <p> Don't cut off any communication cables.</p>  <p>Press the RSD/RMO communication cable in the seal via the side incisions.</p> | |

4.6.8 WiFi/LAN Module Connection (Optional)

For details, please refer to the corresponding Module Installation Guide in the packing.

The appearance of modules may be slightly different. The figure shown here is only for illustration.



5. System Operation

5.1 Inverter Working Mode

The inverter supports several different working modes.

5.1.1 Self Used Mode


Go to the "Hybrid work mode" menu, and select the "Self used mode".

Under Self Used mode, the priority of PV energy consumption will be Load > Battery > Grid, that means the energy produced by PV gives priority to powering local loads, the excess energy is used to charge the battery and the remaining energy is fed into the grid.

This is the default mode to increase self-consumption rate. There are several situations of self-used working mode based on PV energy.


a) Wealthy PV Energy

When PV energy is wealthy, the PV energy will be first consumed by loads, the excess energy will be used to charge the battery and then the remaining energy will be fed into the grid.




b) Limited PV power

When the PV energy is not enough to cover all consumption, the PV energy will be entirely used by loads, and the insufficient part will be supplied by battery. Then still insufficient parts will be supplied by grid.



c) No PV Input

The inverter will first discharge the battery energy for home load consuming when no PV input (such as in the evening or some cloudy or rainy days). If the demand is not met, the loads will consume grid energy.




5.1.2 Feed-in Priority Mode

Go to the "Hybrid work mode" menu, and select the "Feed-in priority mode".

Under this mode, the priority of PV energy consumption will be Load > Grid > Battery, that means the energy produced by PV gives priority to powering local loads, the excess energy is fed into the grid, and the remaining energy is used to charge the battery.


a) Wealthy PV Energy

When PV energy is wealthy, the PV energy will be first consumed by loads. If there is excess PV power, the power will be fed into grid. If there is still PV energy left after load consuming and grid feeding, then the remaining PV power will be used to charge the battery.




b) Limited PV Energy

When PV energy is limited and can not meet the feed-in grid power, the battery will discharge to meet it.



c) No PV Input

The inverter will first discharge the battery energy for home load consuming when no PV input (such as in the evening or some cloudy or rainy days). If the demand is not met, the loads will consume the grid energy.



5.1.3 Time-Based Control Mode

Go to the "Hybrid work mode" menu, and select the "Time-based Control".

Under this mode, you can control the charging and discharging of the inverter. You can set the following parameters based on your requirements:

- Charge and discharge frequency: one time or daily
- Charging start time: 0 to 24 hours
- Charging end time: 0 to 24 hours
- Discharge start time: 0 to 24 hours
- Discharge end time: 0 to 24 hours

You can also choose whether to allow the grid to charge the battery, which is prohibited by default. If the user enables the "Grid charge function", the "Maximum grid charger power" and "Capacity of grid charger end" can be set. When the battery capacity reaches the set value, the grid will stop charging the battery.

5.1.4 Back-up Mode

Go to the "Hybrid work mode" menu, and select the "Back-up Mode".

Under this mode, the priority of PV energy consumption will be Battery > Load > Grid.


This mode aims at charging the battery quickly, and at the same time, you can choose whether to allow AC to charge the battery.

Forbid AC charging

In this mode, the battery can be charged only with PV power, and the charging power varies with PV power.


a) Wealthy PV power

When PV energy is wealthy, PV charges the battery first, then meets the load, and the rest is fed into the grid.



b) Limited PV power

When PV energy is limited, PV gives priority to charging the battery, and the grid directly meet the load demand.




Allow AC charging

In this situation, the battery can be charged both with PV and AC.


a) Wealthy PV power

When PV energy is wealthy, PV charges the battery first, then meets the load, and the rest is fed into the grid.



b) Limited PV power

When the PV energy is not enough to charge the battery, the grid energy will charge the battery as supplement. Meanwhile, the grid energy is consumed by loads.



5.1.5 Off Grid Mode


When the power grid is cut off, the system automatically switches to Off Grid mode.

Under off-grid mode, only critical loads are supplied to ensure that important loads continue to work without power failure.

Under this mode, the inverter can't work without the battery.


a) Wealthy PV power

When PV energy is wealthy, the PV power will be first consumed by critical load, then charge the battery.



b) Limited PV power

When PV energy is limited, BACKUP loads are first powered by PV and then supplemented by battery.




NOTICE

- Under this mode, please complete the output voltage and frequency settings.
- It is better to choose the battery capacity larger than 100Ah to ensure BACKUP function work normally.
- If BACKUP output loads are inductive or capacitive loads, to make sure the stability and reliability of system, it is recommended to configure the power of these loads to be within 50% BACKUP output power range.

5.1.6 On-grid Unbalanced Output

- 1) The normal load is single phase.
 - 2) The three phases of normal load are the same or unbalanced.
- This is the best scheme to meet your needs.

On-grid Unbalanced Output




5.1.7 Back-up Unbalanced Output

- 1) The critical load is single phase.
- 2) The three phases of normal load are the same or unbalanced.

This is the best scheme to meet your needs.

Back-up Unbalanced Output





5.2 Startup/Shutdown Procedure

5.2.1 Startup Procedure

Check and confirm the installation is secure and strong enough and that the system grounding is OK. Then confirm the connections of AC, battery, PV etc. are correct. Confirm the parameters and configurations conform to relevant requirements.


| | | | |
|-----------------|----------|-----------------|--------------------|
| AC Frequency | 50/60Hz | PV Voltage | 160~950V |
| Battery Voltage | 150~600V | Grid AC Voltage | 180~270V(311~467V) |

Startup Procedure



* To act the non-first-time startup, press and hold down the button on the left side of the inverter for about 5 seconds, until you hear the “beep” sound.

Shutdown Procedure



After the inverter is powered off, the remaining electricity and heat may still cause electric shock and body burns. If need to disconnect the inverter cables, please wait at least 10 minutes before touching these parts of inverter.

6. Commissioning

It is necessary to make a complete commissioning of the inverter system. This will essentially protect the system from fire, electric shock or other damages or injuries.

6.1 Inspection

Before commissioning, the operator or installer (qualified personnel) must inspect the system carefully and make sure:

- 1) The system is firmly installed correctly following the contents and notifications of this manual, and there are enough spaces for operation, maintenance and ventilation.
- 2) All the terminals and cables are in good status without any damages.
- 3) No items are left on the inverter or within the required clearance section.
- 4) The PV, battery pack is working normally, and grid is normal.

6.2 Commissioning Procedure

After the inspection and make sure status is right, then start the commissioning of the system.

- 1) Power on the system by referring to the **Startup Procedure** section 5.2.1.
- 2) Setting the parameters on the App according to user's requirement.
- 3) Finish commissioning.

7. User Interface

7.1 LED

This section describes the LED panel. LED indicator includes PV, BAT, GRID, BACKUP, COM, ALARM indicators.

It includes the explanation of indicator states and summary of indicator states under the running state of the machine.



| LED Indicator | Status | Description |
|---------------|--------|---|
| PV | On | PV input is normal. |
| | Blink | PV input is abnormal. |
| | Off | PV is unavailable. |
| BAT | On | Battery is charging. |
| | Blink | Battery is discharging. Battery is abnormal. |
| | Off | Battery is unavailable. |
| GRID | On | GRID is available and normal. |
| | Blink | GRID is available and abnormal. |
| | Off | GRID is unavailable. |
| COM | Blink | Data are communicating. |
| | Off | No data transmission |
| BACKUP | On | BACKUP power is available. |
| | Blink | BACKUP output is abnormal. |
| | Off | BACKUP power is unavailable. |
| ALARM | On | Fault has occurred and inverter shuts down. |
| | Blink | Alarms has occurred but inverter doesn't shut down. |
| | Off | No fault. |

| Details | Code | PV LED | Grid LED | BAT LED | BACKUP LED | COM LED | ALARM LED |
|-------------------------------------|------|--------|----------|---------|------------|---------|-----------|
| PV normal | | ● | ⊙ | ⊙ | ⊙ | ⊙ | ○ |
| No PV | | ○ | ⊙ | ⊙ | ⊙ | ⊙ | ○ |
| PV over voltage | B0 | | | | | | |
| PV under voltage | B4 | | | | | | |
| PV irradiation weak | B5 | ★ | ⊙ | ⊙ | ⊙ | ⊙ | ○ |
| PV string reverse | B7 | | | | | | |
| PV string abnormal | B3 | | | | | | |
| On grid | | | | | | | |
| Bypass output | | ⊙ | ● | ⊙ | ⊙ | ⊙ | ○ |
| Grid over voltage | A0 | | | | | | |
| Grid under voltage | A1 | | | | | | |
| Grid absent | A2 | | | | | | |
| Grid over frequency | A3 | ⊙ | ★ | ⊙ | ⊙ | ⊙ | ○ |
| Grid under frequency | A4 | | | | | | |
| Grid abnormal | A6 | | | | | | |
| Grid over mean voltage | A7 | | | | | | |
| Neutral live wire reversed | A8 | | | | | | |
| Battery in charger | | ⊙ | ⊙ | ● | ⊙ | ⊙ | ○ |
| Battery absent | D1 | ⊙ | ⊙ | ○ | ⊙ | ⊙ | ○ |
| Battery in discharge | | ⊙ | ⊙ | ★★ | ⊙ | ⊙ | ○ |
| Battery under voltage | D3 | | | | | | |
| Battery over voltage | D2 | | | | | | |
| Battery discharge over current | D4 | ⊙ | ⊙ | ★ | ⊙ | ⊙ | ○ |
| Battery over temperature | D5 | | | | | | |
| Battery under temperature | D6 | | | | | | |
| Communication loss (Inverter - BMS) | D8 | | | | | | |
| BACKUP output active | | ⊙ | ⊙ | ⊙ | ● | ⊙ | ⊙ |
| BACKUP output inactive | | ⊙ | ⊙ | ⊙ | ○ | ⊙ | ⊙ |
| BACKUP short circuit | DB | | | | | | |
| BACKUP over load | DC | | | | | | |
| BACKUP output voltage abnormal | D7 | ⊙ | ⊙ | ⊙ | ★ | ⊙ | ○ |
| BACKUP over dc-bias voltage | CP | | | | | | |

| Details | Code | PV LED | Grid LED | BAT LED | BACKUP LED | COM LED | ALARM LED |
|----------------------------------|------|--------|----------|---------|------------|---------|-----------|
| RS485/DB9/BLE/USB | | ☉ | ☉ | ☉ | ☉ | ★ | ☉ |
| Inverter over temperature | C5 | | | | | | |
| Fan abnormal | C8 | | | | | | |
| Inverter in power limit state | CL | | | | | | |
| Data logger lost | CH | ☉ | ☉ | ☉ | ☉ | ☉ | ★ |
| Meter lost | CJ | | | | | | |
| Remote off | CN | | | | | | |
| PV insulation abnormal | B1 | | | | | | |
| Leakage current abnormal | B2 | | | | | | |
| Internal power supply abnormal | C0 | | | | | | |
| Inverter over dc-bias current | C2 | | | | | | |
| Inverter relay abnormal | C3 | | | | | | |
| GFCI abnormal | C6 | | | | | | |
| System type error | C7 | | | | | | |
| Unbalance Dc-link voltage | C9 | | | | | | |
| Dc-link over voltage | CA | ☉ | ☉ | ☉ | ☉ | ☉ | ● |
| Internal communication error | CB | ☉ | ☉ | ☉ | ☉ | ☉ | ● |
| Internal communication loss(E-M) | D9 | | | | | | |
| Internal communication loss(M-D) | DA | | | | | | |
| Software incompatibility | CC | | | | | | |
| Internal storage error | CD | | | | | | |
| Data inconsistency | CE | | | | | | |
| Inverter abnormal | CF | | | | | | |
| Boost abnormal | CG | | | | | | |
| Dc-dc abnormal | CU | | | | | | |

Remark: ● Light on ○ Light off ☉ Keep original status
 ★ Blink 1s and off 1s ★★ Blink 2s and off 2s

7.2 App Setting Guide

7.2.1 Download App


- Scan the QR code on the inverter to download the APP.
- Download APP from the App Store or Google Play.

The APP should access some permissions such as device’s location. You need to grant all access rights in all pop-up windows when installing the APP or setting your phone.

7.2.2 App Architecture

It contains “Cloud Login” and “Local Connection”.

- Cloud login: APP read data from cloud server through API and display inverter parameter
- Local connection: APP read data from inverter through Bluetooth connection with Modbus protocol to display and configure inverter parameter.



7.2.3 Local Setting


■ Access Permission

Before using the local setting, the APP should access some permissions. (You need to grant all access rights in all pop-up windows when installing the APP or setting your phone.) When the APP asks for permission, please click Allow.

■ Connect Inverter

Firstly, open the Bluetooth on your own phone, then open the APP.

Press Local Setting to go to the connect page. This page shows the inverters which you can connect or you have connected. (As shown below) Press the inverter's name to connect it.






■ Quick Setting

1. Connect to the router.

Step 1 Go to Quick Setting page.

Step 2 Click each item to enter the informations, then click [Next](#).




2. Set parameters of power grid

Step 1 Click each item to enter the parameters of power grid.


Step 2 Click [Next](#).

Step 3 Click [Previous](#) back to the previous page.




3. Set parameters of power limit

- Step 1 Click each item to enter the parameters of power limit.
- Step 2 Click [Next](#).
- Step 3 Click [Previous](#) back to the previous page.




4. Set parameters of work mode

- Step 1 Click each item to enter the informations of work mode.
- Step 2 Click [Next](#).
- Step 3 Click [Previous](#) back to the previous page.



5. Start Inverter

- Step 1 Click .
- Step 2 Click [Previous](#) back to the previous page.



■ APP Power Chart

The power chart is showed by Day, Month and Year in our APP. For each exhibition method, it includes both Production and Consumption. We use different icons and colors for different power messages. The icon and color definition as below:



Color: Blue

Definition: Load consumption only from PV



Color: Red

Definition: Battery charge power with PV or AC



Color: Red

Definition: Battery discharge power for load consumption or feed-in grid



Color: Purple

Definition: Consumption power from grid



Color: Purple

Definition: Feed-in grid power from PV or battery



Color: Orange

Definition: Load power



Color: Orange

Definition: PV generating power

1. Query (Daily) Data

Go to [Chart](#) > [Day](#) page. It will show the Daily Production or Consumption Curve in this page. You can swipe the screen left and right to switch the graph.

● Day Chart--Production



The above combination day chart shows the PV production power distributed with three parts:

- load consumption power (Blue)
- battery charge power (Red)
- feed-in grid power (Purple)

- Day Chart--Consumption



The above combination day chart shows the load consumption power from three parts:


- PV generation power (Blue)
- battery discharge power (Red)
- grid power (Purple)

Power supported by PV + power supported by battery + power supported by grid = Load consumption power.

2. Query (Monthly) Data

Go to [Chart](#) > [Month](#) page. It will show the Monthly Production or Consumption Curve in this page. You can swipe the screen left and right to switch the graph.


● Month Chart--Production



The above combination day chart shows the load consumption power from three parts:

- load consumption capacity (Blue)
- battery storage capacity (Red)
- feed-in grid capacity (Purple)

● Month Chart--Consumption




The above combination month chart shows the load consumption capacity from three parts:

- PV generation capacity (Blue)
- battery discharge capacity (Red)
- grid capacity (Purple)

2. Query (Yearly) Data

Go to [Chart](#) > [Year](#) page. It will show the Annually Production or Consumption Curve in this page. You can swipe the screen left and right to switch the graph.


● Year Chart--Production



The above combination year chart shows the distribution of PV production capacity with three parts:

- load consumption capacity (Blue)
- battery storage capacity (Red)
- feed-in grid capacity (Purple)


● Year Chart--Consumption




The above combination year chart shows the load consumption capacity from three parts:

- PV generation capacity (Blue)
- battery discharge capacity (Red)
- grid capacity (Purple)


Local Setting Homepage

This page shows the basic information of inverter. Click  to display the warning message.




History Log

Press **Log** at the bottom and then go to the history log page (as shown below). It contains all the logs for the inverter.



■ **Maintenance**

Go to [Console](#) page. And click [Maintenance](#)




Then you need to enter password in a popup window (as shown below).

Login As Administrator

Enter administrator password

CANCEL
OK


In this page, you can view the basic information like some version information, do some maintaining operations like turn off/on the inverter and manage data.



■ Console


Access Management

Go to [Console](#) > [Access Management](#) page. In this page, you can switch the login permission.



Communication Setting

Go to [Console > Communication Setting](#) page. In this page, you can set or change the parameters of communication settings: Basic Setting, RS485 Setting and Ethernet Setting.



Grid Parameters


Go to [Console](#) > [Grid Parameters](#) page. In this page, you can set or change the parameters of Grid side, as shown in the figure.

Feature Parameters

Go to [Console](#) > [Feature Parameters](#) page. In this page, you can set or change the feature parameters, as shown in the figure.

Power Limit

Go to [Console](#) > [Power Limit](#) page. In this page, you can set or change the parameters of power limit, as shown in the figure.




| Power Limit |
|--|
| Power control Digital Power Meter |
| Meter location On Grid |
| Meter Type CHINT/DTSU666 |
| Power flow direction From grid to inverter |
| Digital meter modbus address 200 |
| Maximum feed in grid power(W) 70000 |

| Feature Parameters |
|--|
| Low Voltage Through <input type="checkbox"/> |
| Island Detection <input type="checkbox"/> |
| Isolation Detection <input type="checkbox"/> |
| Leakage Current Detection(GFCI) <input type="checkbox"/> |
| Terminal Resistor <input type="checkbox"/> |
| Derated Power(%) 0 |
| Power Factor 0.00 |
| Insulation Impedance(kΩ) |
| Leakage Current Point(mA) |
| Unbalanced Voltage Point(%) |
| Moving Average Voltage Limit(V) 0 |

| Grid Parameters |
|--|
| Standard Code Unknown |
| First Connect Delay Time(s) |
| Reconnect Delay Time (s) |
| Frequency High Loss Level_1(Hz) 0 |
| Frequency Low loss Level_1(Hz) 0 |
| Voltage High Loss Level_1(V) 0 |
| Voltage Low Loss Level_1(V) 0 |
| Frequency High Loss Time Level_1(ms) 0 |
| Frequency Low loss Time Level_1(ms) 0 |
| Voltage High Loss Time Level_1(ms) 0 |
| Voltage Low Loss Time Level_1(ms) 0 |
| Frequency High Loss Level_2(Hz) 0 |
| Voltage High Loss Level_2(V) 0 |
| Frequency High Loss Time Level_2(ms) 0 |
| Voltage High Loss Time Level_2(ms) 0 |


Reactive Power Control

Go to [Console > Reactive Power Control](#) page. In this page, you can set or change the Reactive Power Control parameters.



Other Setting

Go to [Console > Other Setting](#) page. In this page, you can set other setting parameters.




Hybrid Setting

Go to [Console > Hybrid Setting](#) page. In this page, you can set Hybrid Setting parameters.

| XXXXXXX | < Hybrid Setting |
|-------------------------------------|--|
| Maintenance > | Hybrid work mode Self used mode |
| Access Management > | Battery type selection Unavailable |
| Communication Setting > | Maximum charger power(W) 0 |
| Grid Parameters > | Capacity of charger end(%) 0 |
| Feature Parameters > | Maximum discharger power(W) 555 |
| Power Limit > | Capacity of discharger end(%) 0 |
| Reactive Power Control > | EPS Output <input checked="" type="checkbox"/> |
| Masking Fault Detection > | Rated output voltage(V) 220V |
| Other Setting > | Off-grid start-up battery capacity(%) 0 |
| Hybrid Setting > | Support Normal Load <input checked="" type="checkbox"/> |
| Logout | Force Charge Start Capacity of charger Start(SOC %) 10 |
| Quick Set... Chart Home Log Console | Force Charge End Capacity of charger End(SOC %) 15 |

8. Maintenance

| | |
|--|---|
|  CAUTION | <p>Before maintaining and commissioning inverter and its peripheral distribution unit, switch off all the charged terminals of the inverter and wait at least 10 minutes after the inverter is powered off.</p> |
|--|---|

8.1 Routine Maintenance

| Items | Check Content | Maintain Content | Maintenance Interval |
|---------------------------------|--|--|----------------------|
| Inverter output status | Statistically maintain the status of electrical yield, and remotely monitor its abnormal status. | N/A | Weekly |
| Inverter cleaning | Check periodically that the heat sink is free from dust and blockage. | Clean periodically the heat sink. | Yearly |
| Inverter running status | Check that the inverter is not damaged or deformed. Check for normal sound emitted during inverter operation. Check and ensure that all inverter communications is running well. | If there is any abnormal phenomenon, replace the relevant parts. | Monthly |
| Inverter electrical connections | Check that all AC, DC and communication cables are securely connected; Check that PGND cables are securely connected; Check that all cables are intact and free from aging. | If there is any abnormal phenomenon, replace the cable or re-connect it. | Semiannually |

8.2 Inverter Troubleshooting

When the inverter has an exception, its basic common warning and exception handling methods are shown below.

| Code | Alarm Information | Suggestions |
|------|--------------------------------|--|
| A0 | Grid over voltage | 1. If the alarm occurs occasionally, possibly the power grid voltage is abnormal for a short time, and no action is required. 2. If the alarm occurs repeatedly, contact the local power station. After receiving approval of the local power bureau, revise the electrical protection parameters settings on the inverter through the App. 3. If the alarm persists for along time, check whether the AC circuit breaker /AC terminals is disconnected or not, or if the grid has a power outage. |
| A1 | Grid under voltage | |
| A3 | Grid over frequency | |
| A4 | Grid under frequency | |
| A2 | Grid absent | Wait till power is restored. |
| B0 | PV over voltage | Check whether the maximum voltage of a single string of input PV modules is greater than the allowable voltage. If the maximum voltage is higher than the standard voltage, modify the number of pv module connection strings. |
| B1 | PV insulation abnormal | 1. Check the insulation resistance against the ground for the PV strings. If a short circuit has occurred, rectify the fault. 2. If the insulation resistance against the ground is less than the default value in a rainy environment, set insulation resistance protection on the App. |
| B2 | Leakage current abnormal | 1. If the alarm occurs occasionally, the inverter can be automatically recovered to the normal operating status after the fault is rectified. 2. If the alarm occurs repeatedly, contact your dealer for technical support. |
| B4 | PV under voltage | 1. If the alarm occurs occasionally, possibly the external circuits are abnormal accidentally. The inverter automatically recovers to the normal operating status after the fault is rectified. 2. If the alarm occurs repeatedly or last a long time, check whether the insulation resistance against the ground of PV strings is too low. |
| C0 | Internal power supply abnormal | 1. If the alarm occurs occasionally, the inverter can be automatically restored, no action required. 2. If the alarm occurs repeatedly, pls. contact the customer service center. |

| | | |
|----|-------------------------------|--|
| C2 | Inverter over dc-bias current | <ol style="list-style-type: none"> 1. If the alarm occurs occasionally, possibly the power grid voltage is abnormal for a short time, and no action is required. 2. If the alarm occurs repeatedly, and the inverter fails to generate power, contact the customer service center. |
| C3 | Inverter relay abnormal | <ol style="list-style-type: none"> 1. If the alarm occurs occasionally, possibly the power grid voltage is abnormal for a short time, and no action is required. 2. If the alarm occurs repeatedly, pls. refer to the suggestions or measures of Grid over voltage. and the inverter fails to generate power, contact the customer service center. If there is no abnormality on the grid side, the machine fault can be determined. (If you open the cover and find traces of damage to the relay, it can be concluded that the machine is faulty.) And pls. contact the customer service center. |
| CN | Remote off | <ol style="list-style-type: none"> 1. Local manual shutdown is performed in APP. 2. The monitor executed the remote shutdown instruction. 3. Remove the communication module and confirm whether the alarm disappears. If it does, replace the communication module. Otherwise, please contact the customer service center. |
| C5 | Inverter over temperature | <ol style="list-style-type: none"> 1. If the alarm occurs occasionally, the inverter can be automatically restored, no action required. 2. If the alarm occurs repeatedly, pls. check the installation site for direct sunlight, good ventilation, and high ambient temperature (Such as installed on the parapet). If the ambient temperature is lower than 45 ° C and the heat dissipation is good, contact the customer service center. |
| C6 | GFCI abnormal | <ol style="list-style-type: none"> 1. If the alarm occurs occasionally, it could have been an occasional exception to the external wiring, the inverter can be automatically recovered, no action required. 2. If it occurs repeatedly or cannot be recovered for a long time, pls. contact customer service to report repair. |
| B7 | PV string reverse | Check and modify the positive and negative polarity of the input of the circuit string. |
| C8 | Fan abnormal | <ol style="list-style-type: none"> 1. If the alarm occurs occasionally, pls. restart the inverter. 2. If it occurs repeatedly or cannot be recovered for a long time, check whether the external fan is blocked by foreign objects. Otherwise, contact customer service. |
| C9 | Unbalance Dc-link voltage | 1. If the alarm occurs occasionally, the inverter can be automatically recovered and no action is required. |
| CA | Dc-link over voltage | 2. If the alarm occurs repeatedly, the inverter cannot work properly. Pls. contact the customer service center. |

| | | |
|----|------------------------------|---|
| CB | Internal communication error | <ol style="list-style-type: none"> 1. If the alarm occurs occasionally, the inverter can be automatically recovered and no action is required. 2. If the alarm occurs repeatedly, the inverter cannot work properly. Pls. contact the customer service center. |
| CC | Software incompatibility | <ol style="list-style-type: none"> 1. If the alarm occurs occasionally, the inverter can be automatically recovered and no action is required. 2. If the alarm occurs repeatedly, the inverter cannot work properly. Pls. contact the customer service center. |
| CD | Internal storage error | <ol style="list-style-type: none"> 1. If the alarm occurs occasionally, the inverter can be automatically recovered and no action is required. 2. If the alarm occurs repeatedly, the inverter cannot work properly. Pls. contact the customer service center. |
| CE | Data inconsistency | <ol style="list-style-type: none"> 1. If the alarm occurs occasionally, the inverter can be automatically recovered and no action is required. 2. If the alarm occurs repeatedly, the inverter cannot work properly. Pls. contact the customer service center. |
| CF | Inverter abnormal | <ol style="list-style-type: none"> 1. If the alarm occurs occasionally, the inverter can be automatically recovered and no action is required. 2. If the alarm occurs repeatedly, the inverter cannot work properly. Pls. contact the customer service center. |
| CG | Boost abnormal | <ol style="list-style-type: none"> 1. If the alarm occurs occasionally, the inverter can be automatically recovered and no action is required. 2. If the alarm occurs repeatedly, the inverter cannot work properly. Pls. contact the customer service center. |
| CJ | Meter lost | <ol style="list-style-type: none"> 1. Check the meter parameter Settings 2. Local APP checks that the communication address of the inverter is consistent with that of the electricity meter 3. The communication line is connected incorrectly or in bad contact 4. electricity meter failure. 5. Exclude the above, if the alarm continues to occur, please contact the customer service center. |

| | | |
|----|------------------------------------|--|
| D2 | Battery over voltage | <ol style="list-style-type: none"> 1. If the alarm occurs occasionally, the inverter can be automatically recovered and no action is required. 2. Check that the battery overvoltage protection value is improperly set. 3. The battery is abnormal. 4. If exclude the above, the alarm continues to occur, please contact the customer service center. |
| D3 | Battery under voltage | <ol style="list-style-type: none"> 1. If the alarm occurs occasionally, the inverter can be automatically recovered and no action is required. 2. Check the communication line connection between BMS and inverter (lithium battery). 3. The battery is empty or the battery voltage is lower than the SOC cut-off voltage. 4. The battery undervoltage protection value is improperly set. 5. The battery is abnormal. 6. If exclude the above, the alarm continues to occur, please contact the customer service center. |
| D4 | Battery discharger over current | <ol style="list-style-type: none"> 1. Check whether the battery parameters are correctly set. 2. Battery undervoltage. 3. Check whether a separate battery is loaded and the discharge current exceeds the battery specifications. 4. The battery is abnormal. 5. If exclude the above, the alarm continues to occur, please contact the customer service center. |
| D5 | Battery over temperature | <ol style="list-style-type: none"> 1. If the alarm occurs repeatedly, please check whether the installation site is in direct sunlight and whether the ambient temperature is too high (such as in a closed room). |
| D6 | Battery under temperature | <ol style="list-style-type: none"> 2. If the battery is abnormal, replace it with a new one. 3. If exclude the above, the alarm continues to occur, please contact the customer service center. |
| D7 | BACKUP output voltage abnormal | <ol style="list-style-type: none"> 1. Check whether the BACKUP voltage and frequency Settings are within the specified range. 2. Check whether the BACKUP port is overloaded. 3. When not connected to the power grid, check whether output is normal. 4. If exclude the above, the alarm continues to occur, please contact the customer service center. |
| D8 | Communication error (Inverter-BMS) | <ol style="list-style-type: none"> 1. Check whether the battery is disconnected. 2. Check whether the battery is well connected with the inverter. 3. Confirm that the battery is compatible with the inverter. It is recommended to use CAN communication. 4. Check whether the communication cable or port between the battery and the inverter is faulty. 5. If exclude the above, the alarm continues to occur, please contact the customer service center. |

| | | |
|----|----------------------------------|--|
| D9 | Internal communication loss(E-M) | 1. Check whether the communication cables between BACKUP, electricity meter and inverter are well connected and whether the wiring is correct 2. Check whether the communication distance is within the specification range |
| DA | Internal communication loss(M-D) | 3. Disconnect the external communication and restart the electricity meter and inverter. 4. If exclude the above, the alarm continues to occur, please contact the customer service center. |
| CU | Dcdc abnormal | 1. If the alarm occurs occasionally, the inverter can be automatically recovered and no action is required. 2. If the alarm occurs repeatedly, please check: 1) Check whether the MC4 terminal on the PV side is securely connected. 2) Check whether the voltage at the PV side is open circuit, ground to ground, etc. If exclude the above, the alarm continues to occur, please contact the customer service center. |
| CP | BACKUP over dc-bias voltage | 1. If the alarm occurs occasionally, the inverter can be automatically recovered and no action is required. 2. If the alarm occurs repeatedly, the inverter cannot work properly. Pls. contact the customer service center. |
| DB | BACKUP short circuit | 1. Check whether the live line and null line of BACKUP output are short-circuited. 2. If it is confirmed that the output is not short-circuited or an alarm, please contact customer service to report for repair. (After the troubleshooting of alarm problems, BACKUP switch needs to be manually turned on during normal use.) |
| DC | BACKUP over load | 1. Disconnect the BACKUP load and check whether the alarm is cleared 2. If the load is disconnected and the alarm is generated, please contact the customer service. (After the alarm is cleared, the BACKUP switch needs to be manually turned on for normal use.) |

8.3 Removing the Inverter




WARNING

Before removing DC input connector, double check DC input switch is turned to OFF to avoid inverter damage and personal injury.

Perform the following procedures to remove the inverter:

Step 1. Disconnect all cables from the inverter, including communications cables, DC input power cables, AC output power cables, and PGND cable, as shown below.





PV Connectors Removing Detail






NOTE

To remove the PV connectors, insert the removal tool into the bayonet according to the position indicated in the drawing, press inward, and then take out the connector outward.

GRID/BACKUP Connectors Removing Detail





Step 2. Remove the inverter from the mounting bracket.
Step 3. Remove the mounting bracket.

9. Technical Specification

| Model | 5K | 6K | 8K | 10K |
|---|--|-------------|--------------|----------------------------|
| Input (PV) | | | | |
| Max. Input Voltage | 1000V | | | |
| MPPT Operating Voltage Range | 160-950V | | | |
| Max. Input Power | 9000W | 9000W | 15000W | 15000W |
| Max. Input Current | 15A/15A | 15A/15A | 20A/30A | 20A/30A |
| Max. Short Circuit Current | 20A/20A | 20A/20A | 30A/40A | 30A/40A |
| Max. Number of PV Strings | 2(1/1) | | 3(1/2) | |
| No. of MPPTs | 2 | | | |
| Input (Battery) | | | | |
| Compatible battery type | Lithium-ion/Lead-acid | | | |
| Battery voltage range | 150-600V | | | |
| Nominal battery voltage (Full load) | 250-600V | | | |
| Max. charge/discharge current | 25A/25A | 25A/25A | 50A/50A | 50A/50A |
| Max. charge/discharge power | 9000W/5800W | 9000W/7000W | 15000W/9100W | 15000W/11300W |
| Lithium battery charge curve | Self-adaption to BMS | | | |
| Output (On Grid) | | | | |
| Rated Grid voltage | 380V/400V/415V 3W+N+PE | | | |
| Rated Grid Frequency | 50Hz/60Hz | | | |
| Grid Frequency Range** | 45Hz-55Hz/55Hz-65Hz | | | |
| Nom. Power (Output) | 5000W | 6000W | 8000W | 10000W |
| Maximum Power (Output) | 5500W | 6600W | 8800W | 11000W |
| Apparent Power (Output) | 5500VA | 6600VA | 8800VA | 11000VA |
| Maximum Current (Output) | 3*8.3A | 3*10A | 3*13.3A | 3*16.7A/3*16A ^① |
| Maximum Current (Input) | 3*25A | 3*25A | 3*25A | 3*25A |
| THDI | <3%(Rated Power) | | | |
| DC Current Injection | <0.5%In | | | |
| Power Factor | > 0.99 Rated power (Adjustable 0.8 Leading - 0.8Lagging) | | | |
| Output (Backup) | | | | |
| Nom. power | 5000VA | 6000VA | 8000VA | 10000VA |
| Maximum power(5min) | 6000VA | 7200VA | 9600VA | 12000VA |
| Maximum power(10s) | 7500VA | 9000VA | 12000VA | 15000VA |
| Rated voltage | 380V/400V/415V 3W+N+PE | | | |
| Backup switch time | 10ms(typical), 20ms(max) | | | |
| THDV | <3% (R Load) ,8% (RCD Load) | | | |
| Efficiency | | | | |
| Max. Efficiency (PV to Grid)* | 98.2% | 98.2% | 98.4% | 98.4% |
| European Efficiency (PV to Grid)* | 97.2% | 97.2% | 97.9% | 97.9% |
| Max. Charge Efficiency (PV to Battery)* | 98% | 98% | 98% | 98% |
| Max. Charge/Discharge Efficiency (Grid to Battery)* | 98% | 98% | 98% | 98% |

①: The specification of “3*16A” is only for British Market.

| Protection | | |
|-----------------------------|--|------|
| DC switch | Support | |
| Anti-islanding protection | Support | |
| AC overcurrent protection | Support | |
| AC short circuit protection | Support | |
| AC over-voltage protection | Support | |
| SPD | DC Type2, AC Type2 | |
| GFCI | Support | |
| AFCI | Optional | |
| RSD | Optional (Tigo/APS) | |
| Insulation detection | Support | |
| General | | |
| Topology | Transformerless | |
| IP Rating | IP65 | |
| Cooling | Natural cooling | |
| Operating Temperature Range | -25°C-60°C | |
| Relative Humidity Range | 0-100% | |
| Max. Operating Altitude | 4000m(>2000m derating) | |
| Noise | <30dB(Measured at 1m) | |
| Dimensions (W*H*D) | 530*550*213mm | |
| Weight | 29.6KG | 32KG |
| HMI & COM | | |
| Display | APP +LED | |
| Communication | WiFi/GPRS/4G/Ethernet(optional); | |
| | BMS(CAN/RS485) | |
| | DRM | |
| | 1*DI | |
| | 2*DO | |
| | METER(RS485) | |
| | RS485 | |
| Certification | | |
| Safety | IEC 62109-1/2 ,IEC 62040,IEC 62477 | |
| EMC | IEC/EN 61000-6-3, IEC 61000-3-11, IEC 61000-3-12, IEC/EN 61000-6-2 | |
| Grid Code | IEC 61727, IEC 62116, EN 50549-1, VDE 4105, AS 4777,CEI 0-21,G98 | |
| Warranty | 5 Years/10 Years (Optional) | |

Remarks :

- *Not yet test ;
- **The range of output voltage and frequency may vary depending upon different grid codes.
- Specifications are subject to change without advance notice.