

Version: EN-UM-1.6



# USER MANUAL

---

## PV 44.0C-614.4 ESS Battery System

# HISTORY

| VERSION | ISSUED       | COMMENTS                                               |
|---------|--------------|--------------------------------------------------------|
| 1.0     | December 24  | First release                                          |
| 1.1     | March 6      | Second release                                         |
| 1.2     | April 10     | Update accessories list, Add installation requirements |
| 1.3     | May 12       | Update the interface definition description            |
| 1.4     | July 11      | Update the list description                            |
| 1.5     | August 07    | Update product labels and notes                        |
| 1.6     | September 15 | Tag Updates                                            |

# Preface

## About This Manual

This manual provides instructions for the installation, electrical connection, and commissioning of the PV 44.0C-614.4 ESS Battery System. It is strongly recommended that installation, operation, and maintenance personnel read this manual and all related documents carefully before using the product. The illustrations in this user manual are for reference only. This user manual is subject to revision without prior notice. (Specific please in kind prevail.)

## Target Group

PV 44.0C-614.4 ESS Battery System must be installed by professional electrical engineers who have obtained relevant qualifications.

## Scope

This manual is applicable to the following Energy storage system:

- PV 44.0C-614.4

## Conventions

The following safety instructions and general information are used within this user manual.

|                                                                                                   |                                                                                                                                                                                            |
|---------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  <b>DANGER</b>   | Indicates an imminently hazardous situation which, if not correctly followed, will result in serious injury or death.                                                                      |
|  <b>WARNING</b>  | Indicates a potentially hazardous situation which, if not correctly followed, will result in serious injury or death.                                                                      |
|  <b>CAUTION</b> | Indicates a potentially hazardous situation which, if not correctly followed, could result in moderate or minor injury.                                                                    |
|  <b>NOTICE</b> | Indicates a potentially hazardous situation which, if not correctly followed, could result in equipment failure to run, or property damage.                                                |
|  <b>NOTE</b>   | Call attention to important information, best practices and tips: supplement additional safety instructions for your better use of the PV 44.0C-614.4 to reduce the waste of you resource. |

# CONTENTS

|                                              |           |
|----------------------------------------------|-----------|
| <b>Preface.....</b>                          | <b>3</b>  |
| About This Manual .....                      | 3         |
| Target Group.....                            | 3         |
| Scope .....                                  | 3         |
| Conventions .....                            | 3         |
| <b>1. Introduction.....</b>                  | <b>5</b>  |
| 1.1 Brief Introduction .....                 | 5         |
| 1.2 Product Features .....                   | 5         |
| 1.3 Product Identity Definition .....        | 6         |
| <b>2. Specification.....</b>                 | <b>7</b>  |
| 2.1 System Performance Parameter.....        | 7         |
| 2.2 Battery Module .....                     | 8         |
| 2.3 Controller.....                          | 10        |
| 2.4 Base .....                               | 14        |
| <b>3. Installation.....</b>                  | <b>16</b> |
| 3.1 Environmental Requirement.....           | 16        |
| 3.2 Recommended Installation Clearance ..... | 18        |
| 3.3 Tools .....                              | 19        |
| 3.4 Safety Gear .....                        | 19        |
| 3.5 Unpacking Inspection .....               | 19        |
| 3.6 Installation .....                       | 21        |
| <b>4. Maintenance .....</b>                  | <b>34</b> |
| 4.1 Trouble Shooting .....                   | 34        |
| 4.2 Replacement of Main Component.....       | 35        |
| 4.3 Battery Maintenance.....                 | 35        |
| <b>5. Storage Recommendations.....</b>       | <b>36</b> |
| <b>6. Shipment .....</b>                     | <b>37</b> |

# 1. Introduction

## 1.1 Brief Introduction

PV 44.0C-614.4 is a high voltage battery storage system based on lithium iron phosphate battery, and it's one of the new energy storage products, it can be used to support reliable power for various types of equipments and systems. PLHS HV is especially suitable for application scene of high power, limited installation space, restricted load-bearing and long cycle life.

## 1.2 Product Features

- The whole module is non-toxic, non-polluting and environmentally friendly;
- Anode material is made from LiFePO<sub>4</sub> with safety performance and long cycle life;
- Battery management system (BMS) has protection functions including over-discharge, over-charge, over-current and high/low temperature;
- The system can automatically manage charge and discharge state and balance current and voltage of each cell;
- Flexible configuration, multiple battery modules can be in serial for expanding voltage and Capacity.
- Adopted natural cooling reduced system entire noise;
- The module has less self-consumption, up to 6 months without charging; no memory effect, excellent performance of shallow charge and discharge;
- Working temperature range is from -20 to 55°C, with excellent discharge performance and cycle life;
- Small size and light weight, standard module is comfortable for installation and maintenance;

### 1.3 Product Identity Definition

Figure 1-1 Rechargeable Lithium-ion Battery Pack Label

■ With heating function

### PrimeVOLT

Product Name: Rechargeable Lithium-ion Battery Pack  
Product Model: PV 5.5P-76.8  
Part NO.: 9518-0502-0AG000



Serial No.: XXXX-XXXXXXX

Rated Energy / Voltage: 5.5 kWh / 76.8 Vdc  
Rated Capacity: 72 Ah  
Protection Class: I  
Operation Voltage Range: 64.8Vdc to 87.6Vdc  
Input / Output Current: 60 A  
Charging Temperature: -10°C~55°C  
Discharging Temperature: -20°C~55°C  
IP Grade: IP65

☒ With heating function  
☐ Without heating function

CAUTION

- \* Do not disassemble the battery pack.
- \* Do not immerse the battery pack in water.
- \* Do not short-circuit the battery.
- \* Do not leave the battery near by fire.

Emergency Situations

- \* If leaking, fire, wet, or damaged, switch off the breaker on the DC side, and stay away from the battery.
- \* Do not touch the leaking liquid.
- \* Do not use water to extinguish the fire, Sand or dry powder extinguisher is usable.









■ Without heating function

### PrimeVOLT

Product Name: Rechargeable Lithium-ion Battery Pack  
Product Model: PV 5.5P-76.8  
Part NO.: 9518-0503-0AG000



Serial No.: XXXX-XXXXXXX

Rated Energy / Voltage: 5.5 kWh / 76.8 Vdc  
Rated Capacity: 72 Ah  
Protection Class: I  
Operation Voltage Range: 64.8Vdc to 87.6Vdc  
Input / Output Current: 60 A  
Charging Temperature: 0°C~55°C  
Discharging Temperature: -20°C~55°C  
IP Grade: IP65

☐ With heating function  
☒ Without heating function

CAUTION

- \* Do not disassemble the battery pack.
- \* Do not immerse the battery pack in water.
- \* Do not short-circuit the battery.
- \* Do not leave the battery near by fire.

Emergency Situations

- \* If leaking, fire, wet, or damaged, switch off the breaker on the DC side, and stay away from the battery.
- \* Do not touch the leaking liquid.
- \* Do not use water to extinguish the fire, Sand or dry powder extinguisher is usable.









Figure 1-2 ESS Battery Controller Label

■ With heating function

### PrimeVOLT

Product Name: ESS Battery Controller  
Product Model: PV 44.0C-614.4  
Part NO.: 9517-0500-0AG000



Serial No.: XXXX-XXXXXXX

Input / Output Current: 60 A  
Protection Class: I  
Charging Temperature: -10°C~55°C  
Discharging Temperature: -20°C~55°C  
IP Grade: IP65

☒ With heating function  
☐ Without heating function

Product Name: Rechargeable Lithium-ion Battery System

□2"B PV 11.0B+H 11.0kWh 153.6V /FP41/149/111[245]2SJM-20+50/90

□3"B PV 16.5B+H 16.5kWh 230.4V /FP41/149/111[245]3SJM-20+50/90

□4"B PV 22.0B+H 22.0kWh 307.2V /FP41/149/111[245]4SJM-20+50/90

□5"B PV 27.5B+H 27.5kWh 384.0V /FP41/149/111[245]5SJM-20+50/90

□6"B PV 33.0B+H 33.0kWh 460.8V /FP41/149/111[245]6SJM-20+50/90

□7"B PV 38.5B+H 38.5kWh 537.6V /FP41/149/111[245]7SJM-20+50/90

□8"B PV 44.0B+H 44.0kWh 614.4V /FP41/149/111[245]8SJM-20+50/90

\* Mark the system configuration-check the instruction









■ Without heating function

### PrimeVOLT

Product Name: ESS Battery Controller  
Product Model: PV 44.0C-614.4  
Part NO.: 9517-0501-0AG000



Serial No.: XXXX-XXXXXXX

Input / Output Current: 60 A  
Protection Class: I  
Charging Temperature: 0°C~55°C  
Discharging Temperature: -20°C~55°C  
IP Grade: IP65

☐ With heating function  
☒ Without heating function

Product Name: Rechargeable Lithium-ion Battery System

□2"B PV 11.0B+H 11.0kWh 153.6V /FP41/149/111[245]2SJM-20+50/90

□3"B PV 16.5B+H 16.5kWh 230.4V /FP41/149/111[245]3SJM-20+50/90

□4"B PV 22.0B+H 22.0kWh 307.2V /FP41/149/111[245]4SJM-20+50/90

□5"B PV 27.5B+H 27.5kWh 384.0V /FP41/149/111[245]5SJM-20+50/90

□6"B PV 33.0B+H 33.0kWh 460.8V /FP41/149/111[245]6SJM-20+50/90

□7"B PV 38.5B+H 38.5kWh 537.6V /FP41/149/111[245]7SJM-20+50/90

□8"B PV 44.0B+H 44.0kWh 614.4V /FP41/149/111[245]8SJM-20+50/90

\* Mark the system configuration-check the instruction









## 2 Specification

### 2.1 System Performance Parameter

Table 2-1 The parameter of Rechargeable Lithium-ion Battery System


| Model Name                                     | PV 11.0B-H                                | PV 16.5B-H   | PV 22.0B-H   | PV 27.5B-H   | PV 33.0B-H   | PV 38.5B-H   | PV 44.0B-H   |
|------------------------------------------------|-------------------------------------------|--------------|--------------|--------------|--------------|--------------|--------------|
| Cell Type                                      | LiFePO <sub>4</sub> , Prismatic Cell      |              |              |              |              |              |              |
| Nominal Capacity                               | 72                                        |              |              |              |              |              |              |
| Module Number                                  | 2                                         | 3            | 4            | 5            | 6            | 7            | 8            |
| Norminal Energy [kWh]                          | 11.05                                     | 16.58        | 22.11        | 27.64        | 33.17        | 38.70        | 44.23        |
| Nominal Voltage [V]                            | 153.6                                     | 230.4        | 307.2        | 384.0        | 460.8        | 537.6        | 614.4        |
| Voltage Range [V]                              | 129.6V~175.2                              | 194.4V~262.8 | 259.2V~350.4 | 324.0V~438.0 | 388.8V~525.6 | 441.6V~624.0 | 518.4V~700.8 |
| Max. Continuous Charge / Discharge Current (A) | 60                                        |              |              |              |              |              |              |
| Rated Charge / Discharge Current               | 36A (0.5C)                                |              |              |              |              |              |              |
| Rated Charge / Discharge Power(KW)             | 5.5                                       | 8.3          | 11.1         | 13.8         | 16.6         | 19.4         | 22.1         |
| Max Charge / Discharge Power(KW)               | 9.2                                       | 13.8         | 18.4         | 23.0         | 27.6         | 32.3         | 36.9         |
| Size (W*D*H) mm                                | 675*360*643                               | 675*360*813  | 675*360*983  | 675*360*1153 | 675*360*1323 | 675*360*1493 | 675*360*1663 |
| Weight (kg)                                    | 127                                       | 176.5        | 226          | 275.5        | 325          | 374.5        | 424          |
| Protection Degree                              | IP65                                      |              |              |              |              |              |              |
| Altitude (m)                                   | 3000                                      |              |              |              |              |              |              |
| Warranty <sup>1</sup>                          | 10 years                                  |              |              |              |              |              |              |
| Cycle Life <sup>2</sup>                        | 6000                                      |              |              |              |              |              |              |
| Operating Temperature (°C) <sup>3</sup>        | -20~55                                    |              |              |              |              |              |              |
| Noise Emission                                 | <35dB                                     |              |              |              |              |              |              |
| Humidity                                       | 5%~95%RH (non-condensing)                 |              |              |              |              |              |              |
| Cooling                                        | Natural Cooling                           |              |              |              |              |              |              |
| Heating                                        | CAN                                       |              |              |              |              |              |              |
| Communication Interface                        | Low temperature charging heating (option) |              |              |              |              |              |              |
| Transmit Certification                         | UN38.3                                    |              |              |              |              |              |              |
| Certification                                  | ROHS                                      |              |              |              |              |              |              |
| Safety                                         | EN 62619, EN62477                         |              |              |              |              |              |              |
| EMC                                            | EN 61000-6-1/2/3/4                        |              |              |              |              |              |              |

**1** 0.5 C @ 25 °C, 90% DoD, 1 cycle per day

**2** 0.5C@ 25 °C, 90% DOD

**3** Charging Temperature: -10-55°C (With heating function)  
0-55°C (Without heating function)  
Discharging Temperature: -20-55°C

The following uses four battery modules as an example:



2.2 Battery Pack




Table 2-2 Product Parameters

| Module Name                        | PV 5.5P-76.8               |
|------------------------------------|----------------------------|
| Cell Technology                    | 72AH-LFP (Prismatic)       |
| Battery Module Energy (kWh)        | 5.5                        |
| Battery Nominal Voltage (Vdc)      | 76.8                       |
| Nominal Capacity (Ah)              | 72                         |
| Battery Module Cell Quantity (pcs) | 24                         |
| Working Voltage Range (Vdc)        | 60-87.6                    |
| Charge Current (Standard) [A]      | 60                         |
| Discharge Current (Standard) [A]   | 60                         |
| Dimensions (W*D*H, mm)             | 675*360*170                |
| Communication Mode                 | CAN                        |
| Ambient Temperature (°C)           | -20~55                     |
| IP Grade                           | IP65 (In stacked up state) |
| Weight (kg)                        | 49.8                       |




Table 2-3 Interface Definition

| Item | Name                        | Definition                                        |
|------|-----------------------------|---------------------------------------------------|
| 1    | Socket interface definition | Battery module output and communication interface |
| 2    | Plug interface definition   | Battery module output and communication interface |




Table 2-4 Port Definition

| Pin No. | Socket interface definition | Plug interface definition |
|---------|-----------------------------|---------------------------|
| 1       | -                           | -                         |
| 2       | PE                          | PE                        |
| 3       | - (Negative)                | - (Negative)              |
| 4       | + (Positive)                | + (Positive)              |
| 5       | Heating film+               | Heating film+             |
| 6       | Heating film-               | Heating film-             |
| 7       | -                           |                           |
| 7.1     | CAN-H                       | CAN-H                     |
| 7.2     | CAN-L                       | CAN-L                     |
| 7.3     | DI 1                        | DO 1                      |
| 7.4     | VCC+                        | VCC+                      |
| 7.5     | VCC-                        | VCC-                      |
| 7.6     | -                           | -                         |
| 7.7     | -                           | -                         |
| 7.8     | -                           | -                         |

## 2.3 Controller

Controller front interface




Table 2-5 Display Area Definition


| Item | Name       | Definition                                                                                 |
|------|------------|--------------------------------------------------------------------------------------------|
| 1    | Status LED | Alarm: yellow light,<br>Protection (Fault): red light<br>Charging/Discharging: green light |
| 2    | SOC LED    | State Of Capacity, green light                                                             |

There are 6 LED indicator, 5 LED gives status of SOC, 1 LED Running Status LED (indicating charging, discharging etc.)


| Status             |                                                                                   |            |
|--------------------|-----------------------------------------------------------------------------------|------------|
| Power Off          |  | no         |
| Stand by           |  | Continuous |
| Charging           |  | Continuous |
| Discharging        |  | Twinkle 2s |
| Warning            |  | Continuous |
| Protection (Fault) |  | Continuous |

| SOC                                                                                                                                                                       |                                                                                   |                                                                                   |                                                                                   |                                                                                   |                                                                                   |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------|-----------------------------------------------------------------------------------|-----------------------------------------------------------------------------------|-----------------------------------------------------------------------------------|-----------------------------------------------------------------------------------|
|                                                                                          |  |  |  |  |  |
| -                                                                                                                                                                         | Real SOC                                                                          | Real SOC                                                                          | Real SOC                                                                          | Real SOC                                                                          | Real SOC                                                                          |
| (0~0]                                                                                                                                                                     | (1~20]                                                                            | (21~40]                                                                           | (41~60]                                                                           | (61~80]                                                                           | (81~100]                                                                          |
| System Self-test: LED1~LED5 Green Running Horse Light (1s)<br>System Upgrade: LED1~LED5 Blue Running Horse Lamp (1s)<br>Charging: The highest lit LED flashes for seconds |                                                                                   |                                                                                   |                                                                                   |                                                                                   |                                                                                   |

### Controller HV-BOX left interface



### Controller HV-BOX right interface



### Controller HV-BOX bottom interface






Table 2-7 Interface Definition

| Item | Name                        | Definition                                        |
|------|-----------------------------|---------------------------------------------------|
| 3    | Ground Point                | PE connecting point                               |
| 4    | Inverter Communication Port | Connect to inverter communication                 |
| 5    | COM Communication Port      | COM: Connect to upper computer communication      |
| 6    | P+ Output Terminal          | DC+ to inverter                                   |
| 7    | P- Output Terminal          | DC- to inverter                                   |
| 8    | DC Breaker                  | DC Breacker 100A                                  |
| 9    | Connector-Plug              | Battery module output and communication interface |

Table 2-8 Controller Connector-Plug Definition

| Pin No. | Module Input Connector |
|---------|------------------------|
| 1       | -                      |
| 2       | PE                     |
| 3       | - (Negative)           |
| 4       | + (Positive)           |
| 5       | Heating Film +         |
| 6       | Heating Film -         |
| 7       |                        |
| 7.1     | CAN-H                  |
| 7.2     | CAN-L                  |
| 7.3     | DI 1                   |
| 7.4     | VCC+                   |
| 7.5     | VCC-                   |
| 7.6     | -                      |
| 7.7     | -                      |
| 7.8     | -                      |



Connector-Plug

2.4 Base

Base top interface






Table 2-9 Interface Definition

| Pin No. | Definition      |
|---------|-----------------|
| 1       | NA              |
| 2       | PE              |
| 3       | 4 Short Circuit |
| 4       | 3 Short Circuit |
| 5       | 6 Short Circuit |
| 6       | 5 Short Circuit |
| 7       |                 |
| 7.1     | 120Ω            |
| 7.2     | 120Ω            |
| 7.3     | -               |
| 7.4     | -               |
| 7.5     | -               |
| 7.6     | -               |
| 7.7     | -               |
| 7.8     | -               |



**CAUTION**

When the DC breaker is tripped off because of over current or short circuit, must wait after 30mins to turn on it again, otherwise may cause the breaker damage.

**Power Switch:** Generally when it is at ON state, you can't turn off it during normal running condition.

**DANGER**

Ensure Power Switch is turned on before waking up the battery. Otherwise it will affect automatic checking process and cause danger.  
DO NOT turn off the "Power Switch" during normal running condition, only in emergency case it could be turned off directly.

## Communication Connector






Table 2-9 Interface Definition

| Inverter Communication Port                                                         |           | COM Communication Port                                                              |      |
|-------------------------------------------------------------------------------------|-----------|-------------------------------------------------------------------------------------|------|
|  |           |  |      |
| PIN 1                                                                               | PCS-485-B | PIN 1                                                                               | TX_P |
| PIN 2                                                                               | PCS-485-A | PIN 2                                                                               | TX_N |
| PIN 3                                                                               | GND       | PIN 3                                                                               | RX_P |
| PIN 4                                                                               | PCS-CAN-H | PIN 4                                                                               | DI+  |
| PIN 5                                                                               | PCS-CAN-L | PIN 5                                                                               | DI-  |
| PIN 6                                                                               | VCC-      | PIN 6                                                                               | RX_N |
| PIN 7                                                                               | N/A       | PIN 7                                                                               | N/A  |
| PIN 8                                                                               | N/A       | PIN 8                                                                               | N/A  |

## 3 Installation

### 3.1 Environmental Requirement



#### 3.1.1 Cleaning

The battery system has high-voltage connectors, and environmental conditions can affect the isolation performance of the system. Before installation and system power on, the dust and iron scurf must be removed to keep a clean environment. And the environment must have certain anti-dust ability. Dust and humidity condition shall be periodic checked during the system continuous operation.



#### 3.1.2 Temperature

ESS battery system working temperature range: -20°C~55°C. Optimum temperature: 15°C~30°C;  
Caution: Out of the working temperature range will cause the battery system over / low temperature alarm or protection which may lead to the cycle life reduction.



#### 3.1.3 Cooling System

It is essential to equip a cooling system to keep the battery system in a relevant temperature range.  
Caution: Out of the working temperature range will cause the battery system over / low temperature alarm or protection which may lead to the cycle life reduction.



#### 3.1.4 Heating System

**Danger:** The module is equipped with a heating system. When the temperature is below 0°C and needs to be charged, to start the battery system, first start the heating system, until the battery module temperature exceeds 0°C to allow charging. The heating system will continue to heat until the battery module temperature reaches 15°C and stops.

**Caution:** Out of the working temperature range will cause the battery system over / low temperature alarm or protection which may lead to the cycle life reduction.



### 3.1.5 Fire-extinguisher System

The room must be equipped with fire-extinguisher system for safety purpose. The fire system needs to be regularly checked to be in normal condition. Refer to the using and maintenance requirements, please follow local fire equipment guidance.



### 3.1.6 Grounding System

Make sure the grounding point for battery system is stable and reliable before the battery installation. If the battery system is installed in an independent equipment cabin (e.g. container), must make sure the grounding of the cabin is stable and reliable.




### 3.1.7 Requirements for Installation Location

- A solid support surface must be available (e.g., concrete or masonry).
- The installation location must be inaccessible to children.
- The installation location must be suitable for the weight and dimensions of the PLHS HV.
- The installation location must not be exposed to direct solar irradiation.
- Keep away from metal conductive dust.
- Keep away from water source, heat source and inflammable and explosive articles.
- The installation location must not be close to the fire.
- The operating temperature should be between  $-20^{\circ}\text{C} \sim +55^{\circ}\text{C}$ .
- The ambient humidity should be between 5-95%.



### 3.1.8 Low Battery Voltage Warning

When the battery is used up, turn off the main battery switch. If the battery is not used for a long time, turn off the main switch of the battery. If not, the battery voltage will be too low, and the machine cannot be started.




### 3.2 Recommended Installation Clearance




Please note that the battery should be installed with a minimum safe clearance from the surrounding equipment or battery. Please refer to the minimum clearance diagram below.

| Space Requirements                                     |          |
|--------------------------------------------------------|----------|
| Min. clearance from left side                          | 300 mm   |
| Min. clearance from right side                         | 300 mm   |
| Min. clearance above ESS Battery System                | 300 mm   |
| Min. clearance between side-by-side ESS Battery System | 300 mm   |
| Min. clearance from back                               | 36~50 mm |



### 3.3 Tools

The tools in the following table could be needed during the installation.

|                                                                                   |                                                                                   |                                                                                   |                                                                                   |                                                                                   |                                                                                   |
|-----------------------------------------------------------------------------------|-----------------------------------------------------------------------------------|-----------------------------------------------------------------------------------|-----------------------------------------------------------------------------------|-----------------------------------------------------------------------------------|-----------------------------------------------------------------------------------|
|  |  |  |  |  |  |
| Network Wire Clamp                                                                | Wire Stripper                                                                     | Crimping Pliers                                                                   | Flat-Head Screwdriver                                                             | Torque Wrench                                                                     | Hexagon Socket                                                                    |
|  |  |  |  |  |  |
| Pen                                                                               | Phillips Screwdriver Bit                                                          | Wrench                                                                            | Tape Measure                                                                      | Drill                                                                             | Level                                                                             |

**Note:**

Use properly insulated tools to prevent accidental electric shock or short circuits.

If insulated tools are not available, cover the entire exposed metal surfaces with available insulated alternatives, except their tip, with electrical tape.

M6x60 expansion bolts delivered with the battery are used to install the floor support and power control module. If the length and quantity of the bolts do not meet installation requirements, prepare M6 stainless steel expansion bolts by yourself. The expansion bolts delivered with the battery are mainly used for solid concrete walls and concrete floors. If other types of walls and floors are used, ensure that the walls and floors meet the loadbearing requirements (one battery expansion module weighs 50 kg) and select the bolts by yourself.

### 3.4 Safety Gear

It is recommended to wear the following safety gear when dealing with the battery system.

|                                                                                     |                                                                                     |                                                                                     |
|-------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|
|  |  |  |
| Insulated gloves                                                                    | Safety goggles                                                                      | Safety shoes                                                                        |





### 3.5 Unpacking Inspection

When the equipment arrives at the installation site, loading and unloading should be performed according to the rules and regulations, to prevent from being exposed under sunlight. Battery should not be installed in direct sunlight. Please refer to Section 3.3.

- Before unpacking, the total number of packages shall be indicated according to the shipping list attached to each package, and the case shall be checked for good condition.
- In the process of unpacking, handle with care and protect the surface coating of the object.
- Open the package, the installation personnel should read the technical documents, verify the list, according to the configuration table and packing list, ensure objects are complete and intact, if the internal packing is damaged, should be examined and recorded in detail.

Packing list is as follows:

**Note:** The four battery modules are used as reference, and the shipment is subject to actual conditions.

| Type      | Item name                      | Quantity | Picture                                                                             | Remarks                                                      |
|-----------|--------------------------------|----------|-------------------------------------------------------------------------------------|--------------------------------------------------------------|
| /         | Battery Controller             | 1 PCS    |    |                                                              |
| /         | Battery Pack                   | N PCS    |    | According to customer selection of electricity configuration |
| /         | Base                           | 1 PCS    |    |                                                              |
| /         | Wall-mounted component adapter | 2 PCS    |    |                                                              |
| /         | Wall mounting brackets         | 1 PCS    |   |                                                              |
| Accessory | Communication cable            | 1 PCS    |  |                                                              |
|           | GND cable                      | 1 PCS    |  |                                                              |
|           | PV connector wrench            | 1 PCS    |  |                                                              |

|           |                                                             |       |  |                                                |
|-----------|-------------------------------------------------------------|-------|--|------------------------------------------------|
| Accessory | Output cable connector " - "                                | 1 PCS |  |                                                |
|           | Output cable connector " + "                                | 1 PCS |  |                                                |
|           | M6 expansion screw                                          | 2 PCS |  | The hole diameter is 8mm and the depth is 60mm |
|           | Screw M6*16mm                                               | 4 PCS |  |                                                |
|           | User manual,<br>Packing list,<br>Outgoing inspection report | 3 PCS |  |                                                |

### 3.6 Installation

#### Installation steps

|       |                          |                                                                             |
|-------|--------------------------|-----------------------------------------------------------------------------|
| Step1 | Installation preparation | 1. The environment is meeting all environmental requirements: "3.1.1~3.1.6" |
| Step2 | Mechanical installation  | 1. Determine ESS battery system placement                                   |
|       |                          | 2. Place the base                                                           |
|       |                          | 3. Install battery module                                                   |
|       |                          | 4. Install controller                                                       |
|       |                          | 5. Install hangers                                                          |
|       |                          | 6. Mark the system configuration                                            |
| Step3 | Battery system self-test | 1. Switch on the DC breaker of the controller                               |
|       |                          | 2. Switch on the "POWER" switch                                             |
|       |                          | 3. Press the "POWER" button for about 3S                                    |
|       |                          | 4. Check the system output voltage                                          |
|       |                          | 5. Shut down the battery system                                             |
| Step4 | Connecting inverter      | 1. Connect output power cable to the inverter                               |
|       |                          | 2. Connect the output communication cable to the inverter                   |
|       |                          | 3. Connect dry contact communication cable                                  |


#### 3.6.1 Installation Preparation

- Make sure the environment is meeting all technical requirements: "3.1.1~3.1.6".
- Prepare equipment and tools for installation.
- Confirm that the DC breaker is in the OFF state to ensure that it is no live operation.


### 3.6.2 Mechanical Installation

#### 3.6.2.1 Place the base


- Choose an appropriate place to set base.
- Take the Controller and base from the package out.



- Put the installed base and feet along the wall, and keep the distance of 36~50mm between the wall and the base.




\*Make the base level



\*Use a level to ensure the base is level in the X and Y directions


### 3.6.2.2 Battery module installation

- Take the battery from the package.




- Install all the ESS Battery Pack modules and controller on the base from bottom to up, follow the sequence B8~B1. Referring to the following figure.

**Warning:** Single battery module is 50kg. It's necessary to arrange more than 1 person to install battery module if without lifting equipment, more than 2 person when install battery module in higher position.




Place the Battery Packs on the base one by one from bottom to top


Do not tip the PACK on one side during installation.



(Prohibit)





(Recommend)




**Warning:** Battery module  $\Delta V$  of single cluster should be less than 0.15V at first installation.

- Install the fixed wall bracket onto the battery pack.






### 3.6.2.3 Controller installation



- Hold the hanger (wall part) where it intends to be mounted on the wall and mark the position of the drill holes. Please pay attention that there may be power cables or other supply lines (e.g., gas or water) routed in the wall. Ensure that no lines are laid in the wall, which could be damaged when drilling holes.
- Set the hanger aside and drill the marked holes.
- Insert screw anchors into the drill holes if the support surface requires them.  
Secure the hanger using screws (recommended M6x16).
- Fix the four hangers (wall parts and controller parts) with M6X12 bolts and nuts, using a cylinder screwdriver to tighten it.

- Mark the System configuration.

|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |            |                                  |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------|----------------------------------|
| <b>PrimeVOLT</b><br>Product Name: ESS Battery Controller<br>Product Model: PV 44.0C-614.4<br>Part NO.: 9517-0500-0A0000                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |            | <br>Serial No.: XXXX-XXXX-XXXXXX |
| Input / Output Current:                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       | 60 A       |                                  |
| Protection Class:                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             | 1          |                                  |
| Charging Temperature:                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         | -10°C~55°C |                                  |
| Discharging Temperature:                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      | -20°C~55°C |                                  |
| IP Grade:                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     | IP65       |                                  |
| <input checked="" type="checkbox"/> With heating function<br><input type="checkbox"/> Without heating function                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |            |                                  |
| Product Name: Rechargeable Lithium-ion Battery System<br><div style="border: 1px solid red; padding: 2px;"> <input checked="" type="checkbox"/> 2*B PV 11.0B-H 11.0kWh 153.6VFP41/149/111[(24S)2S]M1-20+50/90<br/> <input type="checkbox"/> 2*B PV 16.5B-H 16.5kWh 220.2V FP41/149/111[(24S)3S]M2-20+50/90<br/> <input type="checkbox"/> 4*B PV 22.0B-H 22.0kWh 307.2V FP41/149/111[(24S)4S]M2-20+50/90<br/> <input type="checkbox"/> 6*B PV 27.0B-H 27.0kWh 384.0V FP41/149/111[(24S)6S]M2-20+50/90<br/> <input type="checkbox"/> 8*B PV 33.0B-H 33.0kWh 460.8V FP41/149/111[(24S)8S]M2-20+50/90<br/> <input type="checkbox"/> 10*B PV 36.0B-H 36.0kWh 537.6V FP41/149/111[(24S)9S]M2-20+50/90<br/> <input type="checkbox"/> 12*B PV 42.0B-H 42.0kWh 614.4V FP41/149/111[(24S)12S]M2-20+50/90         </div> |            |                                  |
| → Mark the system configuration-check the instruction                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |            |                                  |
|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |            |                                  |




☑ 2\*B PV 11.0B-H 11.0kWh 153.6VFP41/149/111[(24S)2S]M1-20+50/90




Example  
(Stack two batteries and put a dot in the corresponding box.)

### 3.6.3 Battery System Self-Test

3.6.3.1 Switch the controller "DC BREAKER" to the "ON" state.



3.6.3.2 Press and hold the "ON/OFF" button for approximately 3 seconds. The SOC indicator lights LED1-LED5 on the panel will illuminate in blue sequentially, each for 1 second. When the operational indicator changes to "Standby", it indicates the completion of the system's self-check.



3.6.3.3 Use a multimeter to measure the output voltage on the positive and negative ports of the controller.


3.6.3.4 The output voltage should conform to the voltage range in the table "Table 2-1 The parameter of PV 44.0C-614.4 ESS Battery system". Otherwise, the system will be not working properly.

Use a multimeter to check the output voltage is within the normal range.

- **Danger:** The voltage of the battery is too high, please pay attention to do self-protection during the measurement.


### 3.6.4 Shut Down the System.

- Switch off the "ON/OFF" switch.



Press and hold on 3S

- Switch the controller "DC Breaker" to the "OFF" state .





### 3.6.5 Connecting Inverter

Taking 4 battery modules as an example for a single cluster

#### Single-phase ESS Inverter (3K/3K6/4K6/5K/6K)


- Negative DC Power Cable (-)
- Positive DC Power Cable (+)
- - - - - Communication Cable to Inverter
- GND (The battery has two grounding ports, just connect one.)




Insert the positive and negative connectors into the PV+/PV- ports or BAT+/BAT- ports until a "click" sound is heard.

#### Note:

For detailed inverter wiring information, please refer to the inverter user manual.





BMS Communication Cable





## Three-phase ESS Inverter (5K/6K/8K/10K)

- Negative DC Power Cable (-)
- Positive DC Power Cable (+)
- - - Communication Cable to Inverter
- GND (The battery has two grounding ports, just connect one.)





### Note:

For detailed inverter wiring information, please refer to the inverter user manual.





# Three-phase ESS Inverter (12K/15K/20K/25K/30K)

- Negative DC Power Cable (-)
- Positive DC Power Cable (+)
- - - Communication Cable to Inverter
- GND (The battery has two grounding ports, just connect one.)



## Note:

For detailed inverter wiring information, please refer to the inverter user manual.






**DANGER**

Please confirm that the battery system is in the off state before connecting. It may cause electric shock to personnel and damage to the inverter if the battery is connected directly without power off.



Connect output Power Cable to the inverter






P-, Connect to inverter DC- terminal

P+, Connect to inverter DC+ terminal




Connect the output communication cable to the inverter RJ45 CAN port.

- (1) Take off the RJ45 waterproof cover.
- (2) Pass the communication cable through the RJ45 wiring cover.
- (3) Plug the communication cable to the corresponding RJ45 port.
- (4) Tighten RJ45 wiring cover.






Connect external grounding cable



Connect ground point



# **WARNING**

Double check all the power cables and communication cable. Make sure the voltage of the Inverter is in the same level with the battery system.

- (1) Switch on the inverter, to make sure all the power equipments can work normally.
- (2) Start the battery system.

## 4 Maintenance

### 4.1 Trouble Shooting

|                                                                                                 |                                                                                                                                                                                                                                                                |
|-------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  <b>DANGER</b> | <p>The ESS battery system is a high voltage DC system, operated by professional and authorized person only. Before check the failure, must check all the cables connection. Switches are right or not, and if the battery system can be woken up normally.</p> |
|-------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

| No | Problem                                                                           | Possible Reason                                                            | Solution                                                                                                   |
|----|-----------------------------------------------------------------------------------|----------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------|
| 1  | The battery has no voltage output, and "POWER"Light is off.                       | The DC breaker of the controller didn't be turned on                       | Turn on the DC breaker of Controller                                                                       |
| 2  |                                                                                   | The "POWER" switch of the controller box was not switched on               | Switch on the "POWER" button                                                                               |
| 3  |                                                                                   | Battery is in sleep state                                                  | Long press the "POWER" button for about 3s                                                                 |
| 4  |                                                                                   | The fuse in the controller is faulty                                       | Replace fuse                                                                                               |
| 5  |                                                                                   | Battery gets into over-discharged protection                               | Charge the battery to relieve the protection state                                                         |
| 6  | The battery has no voltage output, but "POWER" is on                              | The relay in controller is faulty                                          | Replace a new controller directly                                                                          |
| 7  | When the battery is connected to the inverter, the DC breaker trips automatically | The circuit between the battery and the inverter has a short circuit point | Check for short circuits between the battery and the inverter. Also, check whether the inverter is faulty. |
| 8  | Communication failure between battery and inverter                                | The wrong battery model type is selected on the inverter                   | Select correct battery model type on the inverter                                                          |
| 9  |                                                                                   | Communication cable interruption                                           | Replace communication cable                                                                                |
| 10 |                                                                                   | PIN error in communication cable between inverter and battery              | Replace with the cable corresponding to the CAN signal (the battery side CAN is 4H5L)                      |
| 11 |                                                                                   | Error dialing code on the control box                                      | On the dialing board, use the normal protocol to dial the code                                             |

## 4.2 Replacement of Main Component




**DANGER**

The ESS battery system is a high voltage DC system, only can be operated by professional and authorized person.

### 4.2.1 Replacement of Controller

4.2.1.1 Turn off the whole battery system. Ensure the negative terminal and positive terminal have no power.

4.2.1.2 Remove the four screws on the controller, then remove the controller from the system.



4.2.1.3 Change a new controller. Then fix four screws.

## 4.3 Battery Maintenance



**DANGER**

The maintenance of battery only can be operated by professional and authorized person. you need turn off the battery system firstly when you do some maintenance items.

### 4.3.1 Voltage Inspection

[Periodical Maintenance] Check the voltage of battery system through the monitor software. Check whether the system voltage is normal or not. For example: Check Single cell's voltage is out of rated range or not.

### 4.3.2 SOC Inspection

[Periodical Maintenance] Check the SOC of battery system through the monitor software. Check the SOC of battery string is normal or not.

### 4.3.3 Cables Inspection

[Periodical Maintenance] Visual inspect all the cables of battery system. Check the cables have broken, aging, getting loose or not.

### 4.3.4 Balancing

[Periodical Maintenance] The battery system will become unbalanced if have not be charged fully for a long time. Solution: Preform the balancing maintenance (fully charged) every 3 month. Generally this maintenance progress needs to be completed when external devices such as the monitor software and battery and inverter are in good communication.

### 4.3.5 Output Relay Inspection:

[Periodical Maintenance] Under low load condition (low current), control the output relay OFF and ON to hear the relay has click voice, that's mean this relay can off and on normally.

## 5 Storage Recommendations

- It is recommended that batteries not be stored for a long period. They should be used soon after being deployed onsite. The batteries should be handled according to the following requirements.

| Required Storage Temperature                      | Actual Storage Temperature                         | Recharge Interval | Remarks                                                                                                                                         |
|---------------------------------------------------|----------------------------------------------------|-------------------|-------------------------------------------------------------------------------------------------------------------------------------------------|
| $-15^{\circ}\text{C} < T \leq 55^{\circ}\text{C}$ | $T \leq -15^{\circ}\text{C}$                       | Not allowed       | Not reaching the time for recharge:<br>Use the batteries as soon as possible.<br><br>Reaching the time for recharge:<br>Recharge the batteries. |
|                                                   | $-15^{\circ}\text{C} < T \leq -10^{\circ}\text{C}$ | 6 months          |                                                                                                                                                 |
|                                                   | $-10^{\circ}\text{C} < T \leq +25^{\circ}\text{C}$ | 12 months         |                                                                                                                                                 |
|                                                   | $25^{\circ}\text{C} < T \leq 35^{\circ}\text{C}$   | 9 months          |                                                                                                                                                 |
|                                                   | $35^{\circ}\text{C} < T \leq 55^{\circ}\text{C}$   | 6 months          |                                                                                                                                                 |
|                                                   | $55^{\circ}\text{C} < T$                           | Not allowed       |                                                                                                                                                 |



#### CAUTION

The cycle life of the battery will have relative heavily reduction if not follow the above instructions to store the battery for a long term.

## 6 Shipment

Battery module will pre-charged to 50% SOC or according to customer requirement before shipment. The remaining capacity of battery cell is determined by the storage time and condition after shipment.

- The battery modules meet the UN38.3 certificate standard.
- In particular, special rules for the carriage of goods on the road and the current dangerous goods law, specifically ADR (European Convention on the International Carriage of Dangerous Goods by Road), as amended, must be observed.

